

# EVM User's Guide: TX73L64EVM

## TX73L64 Evaluation Module



### Description

The TX73L64EVM is used for the evaluation of TX73L64 device under various drive strength, different voltage levels and different modes of the device. The EVM contains all necessary control signals and on-board power generation, which reduces the need for external equipment. The evaluation system also includes GUI software for Microsoft® Windows® for easily programming various modes and patterns into the device.


### Features

- Allows control of TX73L64 device using simple GUI via USB
- B-mode or CW mode of transmit can be programmed
- Multiple pattern and Delay profiles can be stored, and the user can switch between them easily in GUI

- Low Noise Amplifier (LNA) and Digital Time Gain Compensation (DTGC) controls allow more control over the receive signal
- Clock and Sync generator present on board
- Sync frequency can be changed using onboard potentiometer
- Option to give external sync
- Uses CMOS serial programming interface
- Error flag register to detect faulty conditions and automatic thermal shutdown
- Evaluate Transmit Performance with 100pF||1kΩ load

### Applications

- [Ultrasound imaging system](#)
- Piezoelectric driver
- [In-probe ultrasound imaging](#)



TX73L64 EVM

## Table of Contents

<b>Description</b> .....	1
<b>Features</b> .....	1
<b>Applications</b> .....	1
<b>1 Evaluation Module Overview</b> .....	3
1.1 Introduction.....	3
1.2 Kit Contents.....	3
1.3 Specification.....	3
1.4 Device Information.....	3
<b>2 Hardware</b> .....	4
2.1 Equipment Setup Overview.....	4
<b>3 Software</b> .....	5
3.1 GUI Software Installation.....	5
3.2 GUI Installation.....	5
<b>4 Implementation Results</b> .....	10
4.1 EVM Testing.....	10
4.2 Measurement Techniques.....	32
<b>5 Hardware Design Files</b> .....	33
5.1 Schematics.....	33
5.2 PCB Layouts.....	41
5.3 Bill of Materials.....	48
<b>6 Additional Information</b> .....	55
6.1 Troubleshooting.....	55
6.2 Trademarks.....	55

# 1 Evaluation Module Overview

## 1.1 Introduction

This user's guide refers to software TX73L64 EVM GUI V.1.0 or higher and requires the Microsoft Windows 7 operating system or above to function.

This user's guide gives a general overview of the TX73L64EVM evaluation module (EVM) and provides a general description of the features and functions to be considered while using this module. The TX73L64EVM provides a platform for evaluating the transmitter under various drive strength, different voltage levels and different modes of the device.

For any further questions regarding the EVM, GUI or device, contact TI support.

### CAUTION

A high voltage DC supply is connected to the TX73L64EVM evaluation module. Therefore, do not leave the EVM powered when unattended to avoid potential injury.

The TX73L64EVM evaluation module is strictly for simulating ultrasound transducer interface development in electrical instrumentation/laboratory development environment. To minimize risk of possible electrical shock and/or radiation hazards, attachment of actual ultrasonic transducers and receivers is prohibited.

## 1.2 Kit Contents

The TX73L64EVM kit contains the following items:

1. TX73L64EVM
2. One mini-USB cable

## 1.3 Specification

The device operates with a  $\pm 5V$ , 500mA supply. The pulser requires  $\pm 100V$ , 500mA supplies.

## 1.4 Device Information

TX73L64 is a highly integrated, high-performance transmitter solution for ultrasound imaging system. The device has total 64 pulser circuits, 64 transmit/ receive switches (referred as T/R or TR switches), 32 LNA circuits, and supports on-chip beamformer (TxBF). The T/R switches also perform a 2:1 multiplexing operation to multiplex inputs of 2 channels to 1 LNA. The device also integrates on-chip floating power supplies that reduce the number of required high voltage power supplies.


TX73L64 has a pulser circuit that generates three-level high voltage pulses (up to  $\pm 100V$ ) that is used to excite multiple channels of an ultrasound transducer. The device supports total 64 outputs. The maximum output current is 1A.

Device can be used as a transmitter solution for many applications like ultrasound imaging, non-destructive testing, SONAR, LIDAR, marine navigation system, brain imaging systems and so on.

## 2 Hardware

### 2.1 Equipment Setup Overview

Figure 2-1 shows the equipment setup required to test the TX73L64EVM.



**Figure 2-1. TX73L64EVM Setup**

#### 2.1.1 Power Supply

The EVM uses a screw-based connector for power supply ports. The EVM requires a  $\pm 5\text{V}$  supply and a high voltage  $\pm 100\text{V}$  supply with a 500mA current range.

#### 2.1.2 USB Interface to PC

USB connection from the TX73L64EVM to the PC is used for communication between the GUI and the EVM. Both USB 2.0 and 3.0 ports are supported. The USB must be connected when testing the device.

### 3 Software

#### 3.1 GUI Software Installation


The TX73L64EVM requires a software to be installed to check the on-chip features of the device. Make sure that no USB connection is made to the EVM until after the installation is complete.

#### 3.2 GUI Installation

##### 1. TX73L64EVM GUI Installation


Download the TX73L64EVM GUI from the mySecureSoftware folder at [www.ti.com/securesoftware](http://www.ti.com/securesoftware).

- a. Unzip the saved file and run the installer executable as administrator by right clicking on the file and selecting *Run as Administrator*. In the TX73L64EVM GUI installer window, click the *Next >* button.




**Figure 3-1. TX73L64EVM GUI Install (License Agreement)**

- b. Read the Texas Instruments License Agreement. Select the *I accept the agreement* radio button, and then click the *Next >* button.




**Figure 3-2. TX73L64EVM GUI Install (Select Destination Location)**




**Figure 3-3. TX73L64EVM GUI Install (Select Project Folder)**

- c. Select the destination folder where the software has to be installed and where the project folder has to be placed (documents folder). Keeping default settings is preferred. The user created scripts are saved in the project folder by default.




**Figure 3-4. TX73L64EVM GUI Install (Installation Ready)**

- d. Create a desktop icon if desired. Click *Next* >.



**Figure 3-5. TX73L64EVM GUI Install (Ready to install)**

- e. Click *Install* and wait for installation.



**Figure 3-6. TX73L64EVM GUI Install (Installing)**




**Figure 3-7. TX73L64EVM GUI Install (FTDI CDM Drivers)**

- f. Click *Extract* and go to the next page.



**Figure 3-8. TX73L64EVM GUI Install (Welcome to the FTDI Installation Wizard)**

- g. Click *Next >* and go to the next page.



**Figure 3-9. TX73L64EVM GUI Install (FTDI License Agreement)**

- h. Accept the license Agreement and click *Next >*.



**Figure 3-10. TX7316EVM GUI Install (Completing the Device Driver Installation Wizard)**

- i. The FTDI drivers have been installed. Now, click *Finish*.



**Figure 3-11. TX7316EVM GUI Install (Completing the TI-Latte Setup Wizard)**

- j. The GUI installation is complete. Click *Finish*.

## 4 Implementation Results

### 4.1 EVM Testing

EVM can be configured and tested in different modes using GUI.

#### 4.1.1 EVM Connection

- Make sure that the power supplies are turned off before connecting to the board
- Apply  $\pm 5V$  to connector J3 (set the current limit of both the supplies to 500mA)
- Apply  $\pm 100V$  to connector J2 (supply can be any value between  $\pm 1.5V$  to  $\pm 100V$ ). Set the current limit to 50mA
- Connect USB cable

#### 4.1.2 Powering up EVM

Make the power supply connection as shown in [Figure 2-1](#).

Connect the USB cable before powering up the EVM.

The EVM requires no specific power supply sequence. Set the  $\pm 5V$  and HV supplies to the expected values.


After powering up the supplies:

- LED D13: ON showing status of USB cable connection.
- LED D17: ON showing status of FTDI.
- LED D9: ON showing status of on board 3.3V LDO.
- LED D10: ON showing status of on board 1.8V LDO.
- LED D1: OFF showing status of device TSHUT pin.
- LED D4: OFF showing status of device TX\_RXZ pin.
- LED D12: OFF showing status of device CRC\_ERR pin.

[Table 4-1](#) lists the expected supply current after power up and hardware reset that include both device and board current.

**Table 4-1. Supply Currents**

Supply	Current (mA)	Supply	Current (mA)
+5V	230	-5V	1
+100V	2.8	-100V	2.8



**Figure 4-1. EVM Power Up State**

### 4.1.3 Testing EVM

Power up the EVM before opening the GUI. Steps to open GUI:

1. To open the GUI, either click the TX73L64 GUI icon on Desktop or write TX73L64 GUI on start menu and click Open.
2. The latte software opens.
3. Go to scripts section in left corner of GUI and select file *Files > Project -> TX73L64 \_GUI* and select file *devInit.py*.
4. Click the run -> buffer option as shown in [Figure 4-2](#). Interactive GUI opens as shown in [Figure 4-4](#). Check the logs section of the GUI. It should be similar to [Figure 4-3](#).
5. Select the TX73L64\_GUI under Tree View to navigate across pages.




Figure 4-2. Latte GUI Window




Figure 4-3. Device initialization Logs





Figure 4-4. TX73L64 Interactive GUI

### 4.1.3.1 Initializing Device

Follow below steps to load and generate known pattern from the device.

1. Navigate to the *Quick Setup* page and click on *Hardware Reset*. This resets any previous settings on the device to the default values and takes approximately 20 seconds. The GUI displays a pop-up message after the hardware is reset.
2. Then click on *Memory Reset* (once per power up cycle is enough). Memory on power up is not reset and contains undefined data. Clicking memory reset button writes 0 to all the memory location. Resetting the memory takes around 10 seconds. The GUI displays a pop-up message after the memory is reset.
3. Click the *Load Sample Patterns* button. This loads a set of predefined patterns into the device.




The screenshot displays the Texas Instruments GUI with the following components:

- Settings List:** A list of configuration options with checkboxes, including Sync Clock Enable, Global PowerDown, Pin Powerdown, Sample CW Mode, TRSW Select Even Channels, TRSW Mux enable, and Auto disable RX.
- Temperature Readout:** A field showing "Temperature 0.0" with a "Read Temp" button.
- Device Registers:** A section with "Address" (0), "Data(Hex)", and "Enable Read Mode" checkbox, along with a "Write" button.
- Board Diagnostics:** A table listing various error flags and their status (all NA):
 

TEMP_SHUT_ERR	→	NA
NO_CLK_ERR	→	NA
SINGLE_LVL_ERR	→	NA
LONG_TRAN_ERR	→	NA
PSV_SUP_ERR	→	NA
M5V_SUP_ERR	→	NA
PHV_RANGE_ERR	→	NA
TRIG_ERR	→	NA
STANDBY_FLAG	→	NA
VALID_FLAG	→	NA
- Action Buttons:** A grid of buttons including Software Reset, Hardware Reset (1), Memory Reset (2), Load Sample Patterns (3), Export Settings, and Import Settings.
- Status Bar:** A "Read Pins" button and three status indicators: TSHUT (NA), CRC ERROR (NA), and TX\_RXZ (NA).


**Figure 4-5. Device Initialization Steps**

- Now check the Board Diagnostics Block. First click the *Reset Display* button and then click *Start Diagnosis*. All the flags must pass the test. The user can also read the device status pins TSHUT, CRC ERROR and TX RXZ by clicking the *Read Pins* button below the Board Diagnostics section.



**Figure 4-6. Checking Error Flags**

- Selecting the *Sync Clock Enable* check box will enable sync. This provides continuous sync signals to the device, and the device starts to transmit the default loaded pattern if HV supply is provided before this step. It is best to keep the sync disabled until the user is ready to transmit.



Setting the sync PRF:

1. The frequency of sync signal is controlled by the resistance R363.



**Figure 4-7. Changing Sync PRF on EVM**

2. Set the sync PRF to as expected by rotating the potentiometer controlling R363.
3. This can be done while probing the Sync test point (TP3) to see the change in PRF live on the scope and adjust accordingly. Make sure to turn off the HV supply when doing this.

### 4.1.3.2 Loading Sample Pattern

After the GUI loads the predefined pattern in the device, select the pattern from the *Profile Select* drop-down menu in the *PAT\_Generate\_CW* page and the figure shows the pattern information. If the sync is enabled, the selected pattern can be probed at the TX test points.




Figure 4-8. Pattern Profile Select Page

## 4.1.4 GUI Control

### 4.1.4.1 Generating New Patterns

Users can define the choice of pulser output pattern in B-mode using *PAT\_Generate\_CW* section.

Steps to define new pattern.


1. Enter number of transitions.
2. Program required level and duration of each transitions. The effective duration of each transition is programmed value + 1 clock cycle.
3. Give the pattern a name.
4. Press *Save Profile*.

By default, the pattern pointer points to the last saved pattern. To enable a different pattern, choose the required profile name from the load pattern profile section (explained in [Saving and Loading Patterns](#)).



#### 4.1.4.2 Saving and Loading Patterns

The GUI has separate options to edit or save pattern profile and to set the pattern pointer. Save profile button writes the pattern data to all 16 pages in memory. The load pattern profile button sets the pattern pointer to the chosen pattern and all 64 channels transmit that specific pattern. This allows the user to save multiple commonly used profiles and quickly switch between different profiles.



#### 4.1.4.3 Setting Channel Controls

The *Ch\_TRSW\_Controls* section allows the user to program settings on specific channels like powering up the pulsers, inverting the pattern and permanently enabling/disabling the TR Switch. Controls are grouped for 4 channels in a widget and every widget takes a 4-bit string as input.

Example: Writing the string *0101* in Ch 4-1 PowerDown powers down channels 1 and 3. Note that the value entered in the field is automatically treated as a string and there is no need to provide the " for the input to specify the string.

To apply a setting to all channels, click the tick box at the top of every column. The individual widgets can still be modified. For example, to power down all channels and power up only channel 1, use all channels power down and then write *1110* in *Ch 4-1 PowerDown* field.



The screenshot shows the Interactive GUI with four columns of channel control settings. Each column has a header with a checkbox for 'All Channels' and a list of channel ranges with 4-bit binary input fields.

Channel PowerDown	Channel Inversion	TRSW Enable	TRSW Disable
All Channels PowerDown <input type="checkbox"/>	All Channels Invert <input type="checkbox"/>	All Channels TRSW Enable <input type="checkbox"/>	All Channels TRSW Disable <input type="checkbox"/>
Ch 4-1 PowerDown: 0000	Ch 4-1 Inversion: 0000	Ch 4-1 TRSW Enable: 0000	Ch 4-1 TRSW Disable: 1010
Ch 8-5 PowerDown: 0000	Ch 8-5 Inversion: 0000	Ch 8-5 TRSW Enable: 0000	Ch 8-5 TRSW Disable: 1010
Ch 12-9 PowerDown: 0000	Ch 12-9 Inversion: 0000	Ch 12-9 TRSW Enable: 0000	Ch 12-9 TRSW Disable: 1010
Ch 16-13 PowerDown: 0000	Ch 16-13 Inversion: 0000	Ch 16-13 TRSW Enable: 0000	Ch 16-13 TRSW Disable: 1010
Ch 20-17 PowerDown: 0000	Ch 20-17 Inversion: 0000	Ch 20-17 TRSW Enable: 0000	Ch 20-17 TRSW Disable: 1010
Ch 24-21 PowerDown: 0000	Ch 24-21 Inversion: 0000	Ch 24-21 TRSW Enable: 0000	Ch 24-21 TRSW Disable: 1010
Ch 28-25 PowerDown: 0000	Ch 28-25 Inversion: 0000	Ch 28-25 TRSW Enable: 0000	Ch 28-25 TRSW Disable: 1010
Ch 32-29 PowerDown: 0000	Ch 32-29 Inversion: 0000	Ch 32-29 TRSW Enable: 0000	Ch 32-29 TRSW Disable: 1010
Ch 36-33 PowerDown: 0000	Ch 36-33 Inversion: 0000	Ch 36-33 TRSW Enable: 0000	Ch 36-33 TRSW Disable: 1010
Ch 40-37 PowerDown: 0000	Ch 40-37 Inversion: 0000	Ch 40-37 TRSW Enable: 0000	Ch 40-37 TRSW Disable: 1010
Ch 44-41 PowerDown: 0000	Ch 44-41 Inversion: 0000	Ch 44-41 TRSW Enable: 0000	Ch 44-41 TRSW Disable: 1010
Ch 48-45 PowerDown: 0000	Ch 48-45 Inversion: 0000	Ch 48-45 TRSW Enable: 0000	Ch 48-45 TRSW Disable: 1010
Ch 52-49 PowerDown: 0000	Ch 52-49 Inversion: 0000	Ch 52-49 TRSW Enable: 0000	Ch 52-49 TRSW Disable: 1010
Ch 56-53 PowerDown: 0000	Ch 56-53 Inversion: 0000	Ch 56-53 TRSW Enable: 0000	Ch 56-53 TRSW Disable: 1010
Ch 60-57 PowerDown: 0000	Ch 60-57 Inversion: 0000	Ch 60-57 TRSW Enable: 0000	Ch 60-57 TRSW Disable: 1010
Ch 64-61 PowerDown: 0000	Ch 64-61 Inversion: 0000	Ch 64-61 TRSW Enable: 0000	Ch 64-61 TRSW Disable: 1010

Notes from the screenshot:  
 - Note: Controls of 4 adjacent channels are grouped together. Each control box takes a 4 bit binary input with LSB - channel n and MSB - channel n+3 with n = 1,5,9,...,61. Complete 4 bit string input has to be entered in every field for the change to take effect.  
 - Note: When "TRSW Select Even Channels" option in Quick Setup Page is Enabled - Disable TRSW for Odd Channels and vice versa.

#### 4.1.4.4 Setting Delay Profile

The *Ch\_Delay\_Profiles* section can be used to store and load multiple delay profiles.

Steps to define a new profile:

1. Enter the required delay for every channel in the corresponding widget. Half clock delays are allowed. Any other decimal value entered is rounded off to the nearest valid value.
2. Give the delay profile a name.
3. Click *Save Profile*. This writes all the delay profiles into device memory.
4. Previously saved profiles can be edited by choosing the required profile, updating the delay values of the required channels and saving again. The profile to edit can be chosen from the drop-down box.
5. Load the required delay profile. This sets the delay pointer to the required profile.

#### Note

Just entering a delay value in for a specific channel in the widget does not reflect on the device. The corresponding profile has to be saved and then loaded for the change to take effect.



To help with setting the delay value for all 64 channels, the GUI supports global delay mode and beamforming delay mode. This updates the channel delay widgets.

These are just software level options in the GUI. The device has no such specific operation modes.

1. For global delay mode:
  - a. Enable *set global delay*.
  - b. Set the expected value in 'global channel delay'.
2. For beamforming delay mode:
  - a. Enable *set Beam Forming delay*.
  - b. Set the expected beamforming start value and incremental step size.

To update the delay of a specific channel after using either of these modes, just deselect the *set global/beamforming delay* check boxes and set the required value in the corresponding widgets for the channel. Then save the profile for the changes to take effect.

Note: Works with respect to BF\_Clock Cycles

Channel 1	0.0	Channel 17	1920.0	Channel 33	3840.0	Channel 49	5760.0
Channel 2	120.0	Channel 18	2040.0	Channel 34	3960.0	Channel 50	5880.0
Channel 3	240.0	Channel 19	2160.0	Channel 35	4080.0	Channel 51	6000.0
Channel 4	360.0	Channel 20	2280.0	Channel 36	4200.0	Channel 52	6120.0
Channel 5	480.0	Channel 21	2400.0	Channel 37	4320.0	Channel 53	6240.0
Channel 6	600.0	Channel 22	2520.0	Channel 38	4440.0	Channel 54	6360.0
Channel 7	720.0	Channel 23	2640.0	Channel 39	4560.0	Channel 55	6480.0
Channel 8	840.0	Channel 24	2760.0	Channel 40	4680.0	Channel 56	6600.0
Channel 9	960.0	Channel 25	2880.0	Channel 41	4800.0	Channel 57	6720.0
Channel 10	1080.0	Channel 26	3000.0	Channel 42	4920.0	Channel 58	6840.0
Channel 11	1200.0	Channel 27	3120.0	Channel 43	5040.0	Channel 59	6960.0
Channel 12	1320.0	Channel 28	3240.0	Channel 44	5160.0	Channel 60	7080.0
Channel 13	1440.0	Channel 29	3360.0	Channel 45	5280.0	Channel 61	7200.0
Channel 14	1560.0	Channel 30	3480.0	Channel 46	5400.0	Channel 62	7320.0
Channel 15	1680.0	Channel 31	3600.0	Channel 47	5520.0	Channel 63	7440.0
Channel 16	1800.0	Channel 32	3720.0	Channel 48	5640.0	Channel 64	7560.0

#### 4.1.4.5 Setting T/R Switch Delays

The *TRSW\_Delay* section can be used to set the TR Switch On and Off delays.

Unlike channel delay, updating the delay value for a widget of a specific channel updates into the device and the change takes effect.

To set the same value to all channels, use the *set global delay* checkbox and enter required value in the corresponding global delay widget.

To update further, clear the check box and edit the delay values for the required channels alone.

Note: Works with respect to BF\_Clock/4 Cycles

Set Global Delay  TRSW Global On Delay 0

Channel 1	0	Channel 17	0	Channel 33	0	Channel 49	0
Channel 2	0	Channel 18	0	Channel 34	0	Channel 50	0
Channel 3	0	Channel 19	0	Channel 35	0	Channel 51	0
Channel 4	0	Channel 20	0	Channel 36	0	Channel 52	0
Channel 5	0	Channel 21	0	Channel 37	0	Channel 53	0
Channel 6	0	Channel 22	0	Channel 38	0	Channel 54	0
Channel 7	0	Channel 23	0	Channel 39	0	Channel 55	0
Channel 8	0	Channel 24	0	Channel 40	0	Channel 56	0
Channel 9	0	Channel 25	0	Channel 41	0	Channel 57	0
Channel 10	0	Channel 26	0	Channel 42	0	Channel 58	0
Channel 11	0	Channel 27	0	Channel 43	0	Channel 59	0
Channel 12	0	Channel 28	0	Channel 44	0	Channel 60	0
Channel 13	0	Channel 29	0	Channel 45	0	Channel 61	0
Channel 14	0	Channel 30	0	Channel 46	0	Channel 62	0
Channel 15	0	Channel 31	0	Channel 47	0	Channel 63	0
Channel 16	0	Channel 32	0	Channel 48	0	Channel 64	0


Note: Works with respect to BF\_Clock/4 Cycles

Set Global Delay  TRSW Global Off Delay 0

Channel 1	0	Channel 17	0	Channel 33	0	Channel 49	0
Channel 2	0	Channel 18	0	Channel 34	0	Channel 50	0
Channel 3	0	Channel 19	0	Channel 35	0	Channel 51	0
Channel 4	0	Channel 20	0	Channel 36	0	Channel 52	0
Channel 5	0	Channel 21	0	Channel 37	0	Channel 53	0
Channel 6	0	Channel 22	0	Channel 38	0	Channel 54	0
Channel 7	0	Channel 23	0	Channel 39	0	Channel 55	0
Channel 8	0	Channel 24	0	Channel 40	0	Channel 56	0
Channel 9	0	Channel 25	0	Channel 41	0	Channel 57	0
Channel 10	0	Channel 26	0	Channel 42	0	Channel 58	0
Channel 11	0	Channel 27	0	Channel 43	0	Channel 59	0
Channel 12	0	Channel 28	0	Channel 44	0	Channel 60	0
Channel 13	0	Channel 29	0	Channel 45	0	Channel 61	0
Channel 14	0	Channel 30	0	Channel 46	0	Channel 62	0
Channel 15	0	Channel 31	0	Channel 47	0	Channel 63	0
Channel 16	0	Channel 32	0	Channel 48	0	Channel 64	0

#### 4.1.4.6 Sample B-mode Pattern


Loading a 3-level, 5MHz pattern from the sample patterns looks like this:



#### 4.1.4.7 Sample CW Pattern

1. Set the HV supply to < 10V to prevent thermal shutdown.
2. Keep supply current limit as 500mA.
3. In the GUI, navigate to *Quick\_Setup* page and check the *Sample CW Mode* checkbox.

This enables a 4MHz NRZ waveform in CW mode in the pulsars of channels 1-8.



The CW waveform can be modified using *CW settings* registers.

By default only 8 channels are enabled as shown below. Having all the 64 channels enabled increases power can cause the device to go in thermal shutdown mode depending on applied supply voltage.

To change the pattern settings, uncheck *CW Enable* widget, update the level period information and select *CW Enable* once again.





Figure 4-9. CW Pattern with Supply of 8V on Scope


#### 4.1.4.8 Setting Trim Options

The transistor delays and Vgs values can be trimmed from the GUI to meet user specifications if required. Separate drop down menus show available trim options for the transistors connected to each supply.



#### 4.1.4.9 LNA and DTGC Settings

The LNA\_DTGC\_Controls page in the GUI has various LNA controls and also allows programming the TGC (Time gain compensation) engine of the device. Refer data sheet to understand how to program the TGC engine and various LNA controls.



#### 4.1.4.10 Reading and Writing Device Registers


The GUI allows user to read and write to device registers by address. For the register addresses and their functionality, refer the data sheet for TX73L64.

To write to device registers, follow the below steps:

1. In the Device Registers section in *Quick\_Setup* tab, enter the register address (in decimal) in the Address field and the value to write (in hexadecimal) in the Data field.
2. Click the *Write* button. The user can check the logs for the details of the register write.

To read from device registers, follow the below steps:

1. In the Device Registers section in *Quick\_Setup* tab, select the *Enable Read Mode* check box.
2. Enter the register address (in decimal) in the Address field.
3. Press enter. The read value is displayed in the Data field in hexadecimal.



### 4.1.A TX73L64EVM Automation

#### 4.1.A.1 Automation using Latte based TX73L64 GUI


##### 4.1.A.1.1 Widgets

Widgets are the elements of interaction in the GUI.

To automate GUI, knowing the name of the widget is important. The widget name can be known by hovering over a particular widget with the cursor.

Example:

- When hovering over the level number widget, the widget name is observed as `~._levelnum`.
- Ignore `~._` and only consider `levelnum` as the widget name.
- `GUI.levelnum` returns the value of the widget.



There are four types of widgets.

- Choice widget
- Text-box widget
- Button widget
- Check-box widget


Each widget has a different way of value declaration and are identified by looking at the widgets.

#### 4.1.A.1.1.1 Choice Widget

This type of widget has a drop-down as shown. To programmatically set a value to the widget, use the following syntax:

GUI.widget\_name = index

Example: GUI.transitionsBox = 1 selects *Transition 2*.



**Figure A-10. Transitions**

Accessing the choice widget using the string inside the drop-down is not possible at the moment. Hence, accessing the choice widget using the index number is preferable and safe. To know the index of the string in the drop-down, expand the drop-down as shown in [Figure A-10](#) and start numbering the string starting from 0. Then use the number and assign the value to the GUI.widget\_name = number. This works for all the widgets which are of drop-down type or choice type.

#### 4.1.A.1.1.2 Button Widget

This type of widget looks like a button. To programmatically click a button, use the following syntax:

GUI.widget\_name = True

Example: GUI.loadSamplePattern = True triggers the saving of profile in the device.



**Figure A-11. Load Sample Patterns**


The button widget is used to execute a set of instructions in the background. This does not have a choice. If the button is clicked, then the GUI assumes the user wants to execute something in the function which is pre-defined by the GUI programmer. In [Figure A-11](#), if the Load Sample Pattern is pressed, this means the user intends to configure the device with sample patterns.

#### 4.1.A.1.1.3 Text-Box Widget

This type of widget has a box as shown. To programmatically set a value to the widget, use the following syntax:

GUI.widget\_name = value


Example: GUI.levelnum = 10 sets the sync Number of levels to 10.



#### Note

Strings must be enclosed in “ ” while integers can be given directly.

GUI.profileName = "My\_profile" names the profile.



#### 4.1.A.1.1.4 Checkbox Widget

This type of widget has a square box.

To programmatically enable the widget, use the following syntax:

GUI.widget\_name = True

To programmatically disable the widget, use the following syntax:

GUI.widget\_name = False



Example: GUI.syncClk = True enables sync.

#### 4.1.A.1.2 Register Operations

It is possible to read and write into the device register by the GUI Device Registers section or by script. To read and write by scripting, follow the below steps.

This skips most of the background functions and directly gets written into or read from the device.

##### 4.1.A.1.2.1 Writing into a Device Register

The syntax for writing into the device is:

**demoTest.jyoti\_dev.RawWriteReg(addr, data)**

where:

addr = Address of the register in the device.

Data = Data to be written.

Refer to the data sheet to see which register corresponds to which functionality in the device.

##### 4.1.A.1.2.2 Reading from a Device Register

The syntax for writing into the device is:

**Value = GUI.JyotiRead(addr)**

where:

addr = Address of the register in the device.

Value = Variable which contains the data inside the register of the device.

#### 4.1.A.1.3 Generating Scripts for Automation through TX73L64 GUI

Follow the procedure below to generate automation scripts.

1. Open the TX73L64 GUI from the Latte and run *devInit.py* (Run → Buffer).
2. Right-click the TX73L64\_GUI profile as shown below, select *Add Script* and double-click to rename to *Automation\_script.py*.

Consider the following example:

1. Initialize the GUI.
2. Enable the Sync.
3. Generate a 4 cycle PHV to MHV transition waveform of 5MHz.
4. Name the profile as *Example*.
5. Power down all the channels except channel 1 and 2.
6. Invert the pattern in channel 2.
7. Set channel 1,2 Delay to 40 nanoseconds (assuming the beamformer clock frequency to be 250MHz).
8. Set the pattern pointer to point to Example by using the index.
9. Set TRSW Delays to 16ns.

#### 4.1.A.1.4 Automation Script

```

setattr (GUI,"memReset", True)      #memory reset the device
setattr (GUI,"hardReset", True)    #hardware reset the device
#delay(1) ##Give an optional delay of 1 second
### Assuming beam-former clock of 250MHZ, one cycle is 4 Nano-second(1/250MHZ
###Enter the transitions information. 5MHz waveform has 200ns period, which is 50 clock cycles
setattr (GUI,"levelnum",2) ## Enter the number of Transitions
setattr (GUI,"transitionsBox",0) ## Select "Transition 1" in the box
setattr (GUI,"level","PHV") ## Set the level to PHV
setattr (GUI,"period",24) ## Set the period to 100nSec by giving 24
setattr (GUI,"transitionsBox",1) ## Select "Transition 2" in the box.
setattr (GUI,"level","MHV") ## Set the level to MHV
setattr (GUI,"period",24) ## Set the period to 100nSec by giving 25
setattr (GUI,"globalRepeat",3) ## Repeating the pattern three more times
setattr (GUI,"profileName","Example") ## Save with a name "Example"
setattr (GUI,"saveProfile", True) ## Saving the profile in device and GUI
setattr (GUI,"allChPdn", True) ## Power down all the channels at once
setattr (GUI,"ch4p1Pdn", "1100") ## Power up Channels 1,2
setattr (GUI,"ch4p1Inv", "0010") ## Invert pattern in Channel 2
###Enter the channel delay information. 40 Nano-second delay is 10 clock cycles
setattr (GUI,"ch1delay", 10)      ## Set Channel 1 delay
setattr (GUI,"ch2delay", 10)      ## Set Channel 2 delay
setattr (GUI,"delProfileName","Profile 1") ## Save with a name "Profile 1"
setattr (GUI,"saveDelProfile", True) ## Saving the profile in device and GUI
###Enter the TRSW delay information. 16 Nano-second delay is 1 clock cycle (divided)
setattr (GUI,"ch1TRon",1) ## Set Channel 1 ON Delay to 16 Nano-Second
setattr (GUI,"ch2TRon",1) ## Set Channel 2 ON Delay to 16 Nano-Second
setattr (GUI,"syncClk", True) ##Enable Sync

```


Copy and paste the above script into the created file and run the file (Run -> Buffer)

**4.1.A.1.5 Automation Results**

The GUI is updated in the following steps.

Sync Clock Enable	<input checked="" type="checkbox"/>
Global PowerDown	<input type="checkbox"/>
Pin Powerdown	<input type="checkbox"/>
Sample CW Mode	<input type="checkbox"/>
TRSW Select Even Channels	<input type="checkbox"/>
TRSW Mux enable	<input type="checkbox"/>
Auto disable RX	<input type="checkbox"/>

**Figure A-12. Quick Setup Tab**



**Figure A-13. PAT\_Generate\_CW Tab**

Note: Controls of 4 adjacent channels are grouped together. Each control box takes a 4 bit binary input with LSB - channel n and MSB - channel n+3 with n = 1,5,9,...61  
Complete 4 bit string input has to be entered in every field for the change to take effect

Note: When "TRSW Select Even Channels" option in Quick Setup Page is Enabled - Disable TRSW for Odd Channels and vice versa

**Channel PowerDown**

All Channels PowerDown

Ch 4-1 PowerDown	1100
Ch 8-5 PowerDown	1111
Ch 12-9 PowerDown	1111
Ch 16-13 PowerDown	1111
Ch 20-17 PowerDown	1111
Ch 24-21 PowerDown	1111
Ch 28-25 PowerDown	1111
Ch 32-29 PowerDown	1111
Ch 36-33 PowerDown	1111
Ch 40-37 PowerDown	1111
Ch 44-41 PowerDown	1111
Ch 48-45 PowerDown	1111
Ch 52-49 PowerDown	1111
Ch 56-53 PowerDown	1111
Ch 60-57 PowerDown	1111
Ch 64-61 PowerDown	1111

**Channel Inversion**

All Channels Invert

Ch 4-1 Inversion	0010
Ch 8-5 Inversion	0000
Ch 12-9 Inversion	0000
Ch 16-13 Inversion	0000
Ch 20-17 Inversion	0000
Ch 24-21 Inversion	0000
Ch 28-25 Inversion	0000
Ch 32-29 Inversion	0000
Ch 36-33 Inversion	0000
Ch 40-37 Inversion	0000
Ch 44-41 Inversion	0000
Ch 48-45 Inversion	0000
Ch 52-49 Inversion	0000
Ch 56-53 Inversion	0000
Ch 60-57 Inversion	0000
Ch 64-61 Inversion	0000

**TRSW Enable**

All Channels TRSW Enable

Ch 4-1 TRSW Enable	0000
Ch 8-5 TRSW Enable	0000
Ch 12-9 TRSW Enable	0000
Ch 16-13 TRSW Enable	0000
Ch 20-17 TRSW Enable	0000
Ch 24-21 TRSW Enable	0000
Ch 28-25 TRSW Enable	0000
Ch 32-29 TRSW Enable	0000
Ch 36-33 TRSW Enable	0000
Ch 40-37 TRSW Enable	0000
Ch 44-41 TRSW Enable	0000
Ch 48-45 TRSW Enable	0000
Ch 52-49 TRSW Enable	0000
Ch 56-53 TRSW Enable	0000
Ch 60-57 TRSW Enable	0000
Ch 64-61 TRSW Enable	0000

**TRSW Disable**

All Channels TRSW Disable

Ch 4-1 TRSW Disable	1010
Ch 8-5 TRSW Disable	1010
Ch 12-9 TRSW Disable	1010
Ch 16-13 TRSW Disable	1010
Ch 20-17 TRSW Disable	1010
Ch 24-21 TRSW Disable	1010
Ch 28-25 TRSW Disable	1010
Ch 32-29 TRSW Disable	1010
Ch 36-33 TRSW Disable	1010
Ch 40-37 TRSW Disable	1010
Ch 44-41 TRSW Disable	1010
Ch 48-45 TRSW Disable	1010
Ch 52-49 TRSW Disable	1010
Ch 56-53 TRSW Disable	1010
Ch 60-57 TRSW Disable	1010
Ch 64-61 TRSW Disable	1010

Figure A-14. Ch\_TRSW\_Controls Tab

**TRSW ON Delays**

Note: Works with respect to BF\_Clock/4 Cycles

Set Global Delay  TRSW Global On Delay

Channel 1	1	Channel 17	0	Channel 33	0	Channel 49	0
Channel 2	1	Channel 18	0	Channel 34	0	Channel 50	0
Channel 3	0	Channel 19	0	Channel 35	0	Channel 51	0
Channel 4	0	Channel 20	0	Channel 36	0	Channel 52	0
Channel 5	0	Channel 21	0	Channel 37	0	Channel 53	0
Channel 6	0	Channel 22	0	Channel 38	0	Channel 54	0
Channel 7	0	Channel 23	0	Channel 39	0	Channel 55	0
Channel 8	0	Channel 24	0	Channel 40	0	Channel 56	0
Channel 9	0	Channel 25	0	Channel 41	0	Channel 57	0
Channel 10	0	Channel 26	0	Channel 42	0	Channel 58	0
Channel 11	0	Channel 27	0	Channel 43	0	Channel 59	0
Channel 12	0	Channel 28	0	Channel 44	0	Channel 60	0
Channel 13	0	Channel 29	0	Channel 45	0	Channel 61	0
Channel 14	0	Channel 30	0	Channel 46	0	Channel 62	0
Channel 15	0	Channel 31	0	Channel 47	0	Channel 63	0
Channel 16	0	Channel 32	0	Channel 48	0	Channel 64	0

**TRSW OFF Delays**

Note: Works with respect to BF\_Clock/4 Cycles

Set Global Delay  TRSW Global Off Delay

Channel 1	0	Channel 17	0	Channel 33	0	Channel 49	0
Channel 2	0	Channel 18	0	Channel 34	0	Channel 50	0
Channel 3	0	Channel 19	0	Channel 35	0	Channel 51	0
Channel 4	0	Channel 20	0	Channel 36	0	Channel 52	0
Channel 5	0	Channel 21	0	Channel 37	0	Channel 53	0
Channel 6	0	Channel 22	0	Channel 38	0	Channel 54	0
Channel 7	0	Channel 23	0	Channel 39	0	Channel 55	0
Channel 8	0	Channel 24	0	Channel 40	0	Channel 56	0
Channel 9	0	Channel 25	0	Channel 41	0	Channel 57	0
Channel 10	0	Channel 26	0	Channel 42	0	Channel 58	0
Channel 11	0	Channel 27	0	Channel 43	0	Channel 59	0
Channel 12	0	Channel 28	0	Channel 44	0	Channel 60	0
Channel 13	0	Channel 29	0	Channel 45	0	Channel 61	0
Channel 14	0	Channel 30	0	Channel 46	0	Channel 62	0
Channel 15	0	Channel 31	0	Channel 47	0	Channel 63	0
Channel 16	0	Channel 32	0	Channel 48	0	Channel 64	0

Figure A-15. TRSW\_Delay Tab

Profile 1

Save Profile
Delete Profile

Profile 1

Setting Channel Delay

Load Delay Profile Profile 1

Set Global Delay

Global Channel Delay 0.0

Set Beam Forming Delay

BF Delay Start 0.0

BF Delay Step 0.0

Creating Delay Profiles


Note: Works with respect to BF\_Clock Cycles

Channel 1	<input style="width: 50px;" type="text" value="10.0"/>	Channel 17	<input style="width: 50px;" type="text" value="0.0"/>	Channel 33	<input style="width: 50px;" type="text" value="0.0"/>	Channel 49	<input style="width: 50px;" type="text" value="0.0"/>
Channel 2	<input style="width: 50px;" type="text" value="10.0"/>	Channel 18	<input style="width: 50px;" type="text" value="0.0"/>	Channel 34	<input style="width: 50px;" type="text" value="0.0"/>	Channel 50	<input style="width: 50px;" type="text" value="0.0"/>
Channel 3	<input style="width: 50px;" type="text" value="0.0"/>	Channel 19	<input style="width: 50px;" type="text" value="0.0"/>	Channel 35	<input style="width: 50px;" type="text" value="0.0"/>	Channel 51	<input style="width: 50px;" type="text" value="0.0"/>
Channel 4	<input style="width: 50px;" type="text" value="0.0"/>	Channel 20	<input style="width: 50px;" type="text" value="0.0"/>	Channel 36	<input style="width: 50px;" type="text" value="0.0"/>	Channel 52	<input style="width: 50px;" type="text" value="0.0"/>
Channel 5	<input style="width: 50px;" type="text" value="0.0"/>	Channel 21	<input style="width: 50px;" type="text" value="0.0"/>	Channel 37	<input style="width: 50px;" type="text" value="0.0"/>	Channel 53	<input style="width: 50px;" type="text" value="0.0"/>
Channel 6	<input style="width: 50px;" type="text" value="0.0"/>	Channel 22	<input style="width: 50px;" type="text" value="0.0"/>	Channel 38	<input style="width: 50px;" type="text" value="0.0"/>	Channel 54	<input style="width: 50px;" type="text" value="0.0"/>
Channel 7	<input style="width: 50px;" type="text" value="0.0"/>	Channel 23	<input style="width: 50px;" type="text" value="0.0"/>	Channel 39	<input style="width: 50px;" type="text" value="0.0"/>	Channel 55	<input style="width: 50px;" type="text" value="0.0"/>
Channel 8	<input style="width: 50px;" type="text" value="0.0"/>	Channel 24	<input style="width: 50px;" type="text" value="0.0"/>	Channel 40	<input style="width: 50px;" type="text" value="0.0"/>	Channel 56	<input style="width: 50px;" type="text" value="0.0"/>
Channel 9	<input style="width: 50px;" type="text" value="0.0"/>	Channel 25	<input style="width: 50px;" type="text" value="0.0"/>	Channel 41	<input style="width: 50px;" type="text" value="0.0"/>	Channel 57	<input style="width: 50px;" type="text" value="0.0"/>
Channel 10	<input style="width: 50px;" type="text" value="0.0"/>	Channel 26	<input style="width: 50px;" type="text" value="0.0"/>	Channel 42	<input style="width: 50px;" type="text" value="0.0"/>	Channel 58	<input style="width: 50px;" type="text" value="0.0"/>
Channel 11	<input style="width: 50px;" type="text" value="0.0"/>	Channel 27	<input style="width: 50px;" type="text" value="0.0"/>	Channel 43	<input style="width: 50px;" type="text" value="0.0"/>	Channel 59	<input style="width: 50px;" type="text" value="0.0"/>
Channel 12	<input style="width: 50px;" type="text" value="0.0"/>	Channel 28	<input style="width: 50px;" type="text" value="0.0"/>	Channel 44	<input style="width: 50px;" type="text" value="0.0"/>	Channel 60	<input style="width: 50px;" type="text" value="0.0"/>
Channel 13	<input style="width: 50px;" type="text" value="0.0"/>	Channel 29	<input style="width: 50px;" type="text" value="0.0"/>	Channel 45	<input style="width: 50px;" type="text" value="0.0"/>	Channel 61	<input style="width: 50px;" type="text" value="0.0"/>
Channel 14	<input style="width: 50px;" type="text" value="0.0"/>	Channel 30	<input style="width: 50px;" type="text" value="0.0"/>	Channel 46	<input style="width: 50px;" type="text" value="0.0"/>	Channel 62	<input style="width: 50px;" type="text" value="0.0"/>
Channel 15	<input style="width: 50px;" type="text" value="0.0"/>	Channel 31	<input style="width: 50px;" type="text" value="0.0"/>	Channel 47	<input style="width: 50px;" type="text" value="0.0"/>	Channel 63	<input style="width: 50px;" type="text" value="0.0"/>
Channel 16	<input style="width: 50px;" type="text" value="0.0"/>	Channel 32	<input style="width: 50px;" type="text" value="0.0"/>	Channel 48	<input style="width: 50px;" type="text" value="0.0"/>	Channel 64	<input style="width: 50px;" type="text" value="0.0"/>

**Figure A-16. Ch\_Delay\_Profiles Tab**

#### 4.1.6 Procedure to Apply External TR\_BF\_SYNC Signal to EVM

1. Open the TX73L64 GUI from the Latte and run *devInit.py* (Run → Buffer(F5)).
2. De-solder the 0Ω resistor R295 and solder a 0Ω resistor at R276
3. Now, connect a signal generator (3.3Vpp) to J12 as shown. Make sure the resistor pads R139 is populated with a 50Ω resistor to act as termination resistor and helpful for better signal integrity.



4. Connect the signal generator (in this context, an arbitrary waveform generator has been used) to J12 to apply external TR\_BF\_SYNC signal.
5. Now go to *Quick\_Setup* tab and check the *Sync Clock Enable* box.

The user can observe the TR\_BF\_SYNC signal applied to the device on pin (Synchronizer TP3).

## 4.2 Measurement Techniques

The following subsections describe the measurement techniques to be used while testing the device.

### 4.2.1 Rise and Fall Times

Rise and fall times of the device must be measured from 10% to 90% of the peak to peak output voltage. For example, for a  $\pm 100\text{V}$  output swing, the thresholds used for the measurement must be  $\pm 80\text{V}$ .

### 4.2.2 Linearity

Linearity is an important parameter of the device, and is measured by following these steps:

1. Configure the device in the required output pattern.
2. Capture the device output on the oscilloscope by triggering TR\_BF\_SYNC signal.
3. Invert the output pattern.
4. Again capture the device output on the oscilloscope by triggering TR\_BF\_SYNC signal.
5. Post process the data for pulse cancellation and take the FFT to check the linearity.

## 5 Hardware Design Files

### 5.1 Schematics

Figure 5-1 through Figure 5-8 show the functional block diagram of EVM and the schematics.




Figure 5-1. Functional Block Diagram



RX PINS AND LOADS



RX load resistors and capacitor values are for evaluation purposes only.  
 Use appropriate values in your own design.




Figure 5-3. Schematic 2

TRANSMITTER OUTPUT AND LOADS




Figure 5-4. Schematic 3

Power Supplies and LDOs




Figure 5-5. Schematic 4




Figure 5-6. Schematic 5

## CLK Generation

## Clocking options in TX73L64

Clkoning Option 1 : OSC\_250MHz  
Install R25, R26, R150 and uninstallo R20, R29, R173.  
The clock frequency is fixed to 200.0MHz

Clkoning Option 2 : ExternalClock  
Install R20,R29,R173 and uninstallo R25,R26,R150.  
Provide a CMOS clock (0V->2.5V) to J4 SMA

External SYNC : Solder Re resistor R276 and desolder R295  
Provide CMOS SYNC signal to J13 (0V->2.5V)




Figure 5-7. Schematic 6






Figure 5-8. Schematic 7

## 5.2 PCB Layouts


Figure 5-9 to Figure 5-22 show the different PCB layers.




**Figure 5-9. PCB Layer 1 (Top Assembly Drawing)**




**Figure 5-10. PCB Layer 2 (Bottom Assembly Drawing)**




**Figure 5-11. PCB Layer 3 (Signal 1)**




**Figure 5-12. PCB Layer 4 (Ground2/Power 1)**




**Figure 5-13. PCB Layer 5 (Signal 2)**




**Figure 5-14. PCB Layer 6 (Ground 3/Signal 3)**




**Figure 5-15. PCB Layer 7 (Ground 4/Signal 4)**




**Figure 5-16. PCB Layer 8 (Signal 5)**




**Figure 5-17. PCB Layer 9 (Ground 5/Power 2)**



**Figure 5-18. PCB Layer 10 (Signal 6)**



**Figure 5-19. PCB Layer 11 (Ground 6)**



**Figure 5-20. PCB Layer 12 (Bottom Layer)**



## 5.3 Bill of Materials

**Table 5-1. Bill of Materials**

Designator	Quantity	Value	Part Number	Manufacturer	Description	Package Reference	Fitted
!PCB1	1		DC390	Any	Printed Circuit Board		Fitted
C1, C285, C286	3	0.1 $\mu$ F	GRM155R71C104KA88D	MuRata	CAP, CERM, 0.1 $\mu$ F, 16V, $\pm$ 10%, X7R, 0402	0402	Fitted
C2, C5, C6, C22, C71, C72, C73, C74, C75, C76, C77, C78, C79, C80, C81, C82, C83, C84, C86, C87, C88, C89, C90, C91, C92, C93, C94, C95, C96, C97, C98, C132	32	27pF	C0402C270J5GACTU	Kemet	CAP, CERM, 27pF, 50V, $\pm$ 5%, C0G/NP0, 0402	0402	Fitted
C3, C7	2	10 $\mu$ F	200LLE10MEFC8X11.5	Rubycon	CAP, AL, 10 $\mu$ F, 200V, $\pm$ 20%, TH	RCAP_8x11.5mm	Fitted
C4, C8	2	0.1 $\mu$ F	C1206C104K2RACTU	Kemet	CAP, CERM, 0.1 $\mu$ F, 200V, $\pm$ 10%, X7R, 1206	1206	Fitted
C9, C20	2	10 $\mu$ F	EEE-FK1V100R	Panasonic	CAP, AL, 10 $\mu$ F, 35V, $\pm$ 20%, 0.7 $\Omega$ , AEC-Q200 Grade 2, SMD	SMT Radial C	Fitted
C10, C13, C14, C16, C18, C19, C21, C23, C31, C34, C35, C36, C46, C50, C53, C103, C104, C105, C106, C107, C120, C127, C128, C136, C137, C138, C139, C171, C250, C279, C280, C283	32	0.1 $\mu$ F	0402YC104KAT2A	AVX	CAP, CERM, 0.1 $\mu$ F, 16V, $\pm$ 10%, X7R, 0402	0402	Fitted
C11, C12, C37, C170	4	4.7pF	06035A4R7CAT2A	AVX	CAP, CERM, 4.7 $\mu$ F, 50V, $\pm$ 5%, C0G/NP0, 0603	0603	Fitted
C15, C17, C49, C172	4	4.7 $\mu$ F	C0805C475K3PACTU	Kemet	CAP, CERM, 4.7 $\mu$ F, 25V, $\pm$ 10%, X5R, 0805	0805	Fitted

**Table 5-1. Bill of Materials (continued)**

Designator	Quantity	Value	Part Number	Manufacturer	Description	Package Reference	Fitted
C24, C70, C85, C151, C153, C155, C157, C176, C192, C206, C208, C209, C210, C214, C216, C217, C218, C219, C220, C221, C222, C223, C224, C225, C226, C227, C228, C229, C230, C231, C232, C233, C234, C235, C236, C237, C238, C239, C240, C241, C242, C243, C244, C245, C246, C247, C248, C249, C251, C252, C253, C254, C255, C256, C257, C258, C259, C260, C261, C262, C263, C264, C265, C266	64	100pF	AC0603JRNPOYBN101	Yageo	CAP, CERM, 100pF, 250V, ±5%, C0G/NP0, AEC-Q200 Grade 1, 0603	0603	Fitted
C25	1	10µF	GRM188R60J106ME47D	MuRata	CAP, CERM, 10µF, 6.3V, ±20%, X5R, 0603	0603	Fitted
C26, C27	2	0.01µF	520L103KT16T	AT Ceramics	CAP, CERM, 0.01µF, 16V, ±10%, X7R, 0402	0402	Fitted
C28, C38, C39, C40, C41, C42, C43, C44, C57, C58, C59, C60, C61, C62, C66, C67	16	0.1µF	C2012X7T2E104K125AA	TDK	CAP, CERM, 0.1µF, 250V, ±10%, X7T, 0805	0805	Fitted
C29, C166, C169, C277	4	0.1µF	C1005X5R1A104K050BA	TDK	CAP, CERM, 0.1µF, 10V, ±10%, X5R, 0402	0402	Fitted
C30, C32, C33, C129	4	4.7µF	CL05A475MP5NRNC	Samsung Electro-Mechanics	CAP, CERM, 4.7µF, 10V, ±20%, X5R, 0402	0402	Fitted
C45, C47, C48, C51, C52, C54, C55, C56, C68, C69	10	0.1µF	C0603X6S1C104K030BC	TDK	CAP, CERM, 0.1µF, 16V, ±10%, X6S, 0201	0201	Fitted
C140, C141	2	18pF	06035A180JAT2A	AVX	CAP, CERM, 18pF, 50V, ±5%, C0G/NP0, 0603	0603	Fitted
C267	1	6.8pF	CC0603CRNPO0BN6R8	Yageo	CAP, CERM, 6.8pF, 100V, ±3.7%, C0G/NP0, 0603	0603	Fitted
C278	1	12nF	CC0402KRX7R7BB123	Yageo	0.012µF ±10% 16V Ceramic Capacitor X7R 0402 (1005 Metric)	0402	Fitted
C281	1	100pF	0603ZC101KAT2A	AVX	CAP, CERM, 100pF, 10V, ±10%, X7R, 0603	0603	Fitted
C282	1	0.47µF	04026D474KAT2A	AVX	CAP, CERM, 0.47µF, 6.3V, ±10%, X5R, 0402	0402	Fitted
D1, D4, D9, D10, D12, D13, D17	7	Red	CMD17-21SRC/TR8	Visual Communications Company, LLC	LED, Red, SMD	2x1.25mm	Fitted

**Table 5-1. Bill of Materials (continued)**

Designator	Quantity	Value	Part Number	Manufacturer	Description	Package Reference	Fitted
D3, D6	2	110V	UDZLVTE-17110	Rohm	Diode, Zener, 110V, 200mW, SOD-323F	SOD-323F	Fitted
D7, D8	2	6V	MMSZ5233B-7-F	Diodes Inc.	Diode, Zener, 6V, 500mW, SOD-123	SOD-123	Fitted
FB1	1	120Ω	BLM18SG121TN1D	MuRata	Ferrite Bead, 120Ω @ 100MHz, 3A, 0603	0603	Fitted
H1, H2, H3, H4	4		NY PMS 440 0025 PH	B&F Fastener Supply	Machine Screw, Round, #4-40 x 1/4, Nylon, Phillips panhead	Screw	Fitted
H5, H6, H7, H8	4		1902C	Keystone	Standoff, Hex, 0.5"L #4-40 Nylon	Standoff	Fitted
J1, J5, J6, J10	4		PPTC252LFBN-RC	Sullins Connector Solutions	Receptacle, 2.54mm, 25x2, Tin, TH	Receptacle, 2.54mm, 25x2, TH	Fitted
J2, J3	2		1725669	Phoenix Contact	Terminal Block, 3x1, 2.54mm, TH	Terminal Block, 3x1, 2.54mm, TH	Fitted
J4, J12, J14	3		901-144-8RFX	Amphenol RF	SMA Straight Jack, Gold, 50Ω, TH	SMA Straight Jack, TH	Fitted
J7, J13, J16	3		TSW-103-07-G-S	Samtec	Header, 100mil, 3x1, Gold, TH	3x1 Header	Fitted
J9	1		67803-8020	Molex	Connector, Receptacle, USB - mini AB, R/A, SMD	Receptacle, 5-Leads, Body 9.9x9mm, R/A	Fitted
R1, R2, R4, R5, R46, R47, R48, R49, R50, R51, R53, R54, R55, R56, R57, R58, R59, R60, R61, R63, R64, R68, R69, R70, R71, R73, R75, R76, R80, R81, R82, R83	32	1.6k	CRCW04021K60JNED	Vishay-Dale	RES, 1.6 k, 5%, 0.063 W, AEC-Q200 Grade 0, 0402	0402	Fitted
R3, R6	2	100k	TNPW1206100KBEEA	Vishay-Dale	RES, 100 k, 0.1%, 0.25 W, AEC-Q200 Grade 1, 1206	1206	Fitted
R7	1	5.1k	CRCW04025K10JNED	Vishay-Dale	RES, 5.1 k, 5%, 0.063 W, AEC-Q200 Grade 0, 0402	0402	Fitted
R8, R135, R250	3	18k	CRCW040218K0JNED	Vishay-Dale	RES, 18 k, 5%, 0.063 W, AEC-Q200 Grade 0, 0402	0402	Fitted
R9	1	100	CRCW0402100RJNED	Vishay-Dale	RES, 100, 5%, 0.063 W, AEC-Q200 Grade 0, 0402	0402	Fitted
R10, R136, R251	3	10.0k	CRCW040210K0DHEDP	Vishay-Dale	RES, 10.0 k, 0.5%, 0.063 W, AEC-Q200 Grade 0, 0402	0402	Fitted
R11	1	3.60k	RG1608P-362-B-T5	Susumu Co Ltd	RES, 3.60 k, 0.1%, 0.1 W, 0603	0603	Fitted

**Table 5-1. Bill of Materials (continued)**

Designator	Quantity	Value	Part Number	Manufacturer	Description	Package Reference	Fitted
R12, R15, R16, R18, R25, R26, R27, R28, R30, R31, R32, R33, R34, R35, R36, R37, R38, R39, R150, R174, R242, R243, R244, R245, R246, R249	26		ERJ-2GE0R00X	Panasonic	RES, 0, 5%, 0.1 W, AEC-Q200 Grade 0, 0402	0402	Fitted
R13, R110, R124, R130	4	1.0k	CRCW04021K00JNED	Vishay-Dale	RES, 1.0 k, 5%, 0.063 W, AEC-Q200 Grade 0, 0402	0402	Fitted
R14	1	499	CRCW0402499RFKED	Vishay-Dale	RES, 499, 1%, 0.063 W, AEC-Q200 Grade 0, 0402	0402	Fitted
R17	1	0.1	ERJ-L03KF10CV	Panasonic	RES, 0.1, 1%, 0.1 W, AEC-Q200 Grade 1, 0603	0603	Fitted
R43, R44, R45, R279	4	100	ERJ-2GEJ101X	Panasonic	RES, 100, 5%, 0.1 W, AEC-Q200 Grade 0, 0402	0402	Fitted
R129	1	12.0k	CRCW040212K0FKED	Vishay-Dale	RES, 12.0 k, 1%, 0.063 W, AEC-Q200 Grade 0, 0402	0402	Fitted
R134	1	2.2k	CRCW04022K20JNED	Vishay-Dale	RES, 2.2 k, 5%, 0.063 W, AEC-Q200 Grade 0, 0402	0402	Fitted
R139, R565	2	49.9	TNPW060349R9BEEA	Vishay-Dale	RES, 49.9, 0.1%, 0.1 W, AEC-Q200 Grade 1, 0603	0603	Fitted
R141, R145	2		ERJ-3GEYJ100V	Panasonic	Thick Film Resistors - SMD 0603 10ohms 5% AEC-Q200	0603	Fitted
R158, R161, R162, R284, R285	5	10k	ERJ-2GEJ103X	Panasonic	RES, 10 k, 5%, 0.1 W, AEC-Q200 Grade 0, 0402	0402	Fitted
R167, R170	2	0.02	RL0603FR-070R02L	Yageo America	RES, 0.02, 1%, 0.1 W, AEC-Q200 Grade 0, 0603	0603	Fitted
R252, R253	2	150	RT0603BRD07150RL	Yageo America	RES, 150, 0.1%, 0.1 W, 0603	0603	Fitted
R263, R264, R265, R293, R295, R366, R368	7	0	ERJ-2GE0R00X	Panasonic	RES, 0, 5%, 0.1 W, AEC-Q200 Grade 0, 0402	0402	Fitted
R266, R267	2	56.2k	CRCW040256K2FKED	Vishay-Dale	RES, 56.2 k, 1%, 0.063 W, AEC-Q200 Grade 0, 0402	0402	Fitted
R275	1	1.0k	CRCW04021K00JNED	Vishay-Dale	RES, 1.0 k, 5%, 0.063 W, 0402	0402	Fitted
R296	1	0	CRCW04020000Z0ED	Vishay-Dale	RES, 0, 5%, 0.063 W, AEC-Q200 Grade 0, 0402	0402	Fitted

**Table 5-1. Bill of Materials (continued)**

Designator	Quantity	Value	Part Number	Manufacturer	Description	Package Reference	Fitted
R347, R352, R362, R365, R369, R371, R373, R387, R389, R391, R393, R395, R397, R399, R404, R406, R408, R410, R432, R434, R436, R438, R440, R442, R444, R446, R448, R450, R452, R454, R468, R470, R472, R474, R476, R478, R480, R482, R484, R486, R488, R490, R504, R506, R508, R510, R512, R514, R516, R518, R520, R522, R524, R526, R540, R542, R544, R546, R548, R550, R552, R554, R560, R562	64	0	5106	Keystone	RES, 0, 1%, 0.5 W, 0805	0805	Fitted
R361	1	12	CRCW040212R0JNED	Vishay-Dale	RES, 12, 5%, 0.063 W, AEC-Q200 Grade 0, 0402	0402	Fitted
R363	1	100kΩ	CT-94EW104	Nidec Components	100kΩ 0.5W, 1/2W PC Pins Through Hole Trimmer Potentiometer Cermet 18.0 Turn Top Adjustment	PTH_POTEN_9MM6_4MM8	Fitted
R564	1	1.02k	CRCW12061K02FKEA	Vishay-Dale	RES, 1.02 k, 1%, 0.25W, AEC-Q200 Grade 0, 1206	1206	Fitted
S1	1		EVQ-5PN04K	Panasonic	Switch, SPST-NO, Off-Mom, 0.05A, 12 VDC, SMD	6x3.5mm	Fitted
SH-J1, SH-J2, SH-J3	3		QPC02SXGN-RC	Sullins	CONN JUMPER S2 (1 x 2) Position Shunt Connector Black Open Top 0.100" (2.54mm) GoldHORTING .100" GOLD	JUMPER	Fitted
T1	1		ADT4-1WT+	Minicircuits	RF Transformer, 50Ω, 2 to 775MHz, SMT	CD542	Fitted
TP1, TP2, TP3, TP4, TP5, TP43, TP50, TP52	8		5000	Keystone Electronics	Test Point, Miniature, Red, TH	Red Miniature Testpoint	Fitted
TP10, TP11, TP12, TP13	4		5001	Keystone Electronics	Test Point, Miniature, Black, TH	Black Miniature Testpoint	Fitted
TP18, TP28, TP40, TP41, TP42, TP54	6		5004	Keystone Electronics	Test Point, Miniature, Yellow, TH	Yellow Miniature Testpoint	Fitted
U1	1		TX73L64ZBX	Texas Instruments	3-Level, 64-Channel Transmitter with On-Chip Beamformer, T/R Switch, 32 Channel Multiplexed receivers with LNA	FCBGA196	Fitted

**Table 5-1. Bill of Materials (continued)**

Designator	Quantity	Value	Part Number	Manufacturer	Description	Package Reference	Fitted
U3	1		ISO6740FDWR	Texas Instruments	General-purpose, quad-channel, 4/0 digital isolator 16-SOIC -40 to 125	SOIC16	Fitted
U4	1			Texas Instruments	CMOS Low-Power Monostable/Astable Multivibrator, D0014A, LARGE T&R	D0014A	Fitted
U5	1		ISO6741DWR	Texas Instruments	General-purpose, quad-channel, 3/1 digital isolator 16-SOIC -40 to 125	SOIC16	Fitted
U6, U8	2		ISO6742DWR	Texas Instruments	General-purpose, quad-channel, 2/2 digital isolator	SOIC16	Fitted
U7	1		FT4232H-56Q-TRAY	FTDI	Future Technology Devices International Ltd FT4232H Quad High Speed USB to Multipurpose UART/MPSSE IC, VQFN-56	VQFN-56	Fitted
U10	1		93LC46BT-I/SN	Microchip	1K Microwire Compatible Serial EEPROM	SOIC-8	Fitted
U15	1		TPS79901DDCR	Texas Instruments	Single Output High PSRR LDO, 200mA, Adjustable 1.2 to 6.5V Output, 2.7 to 6.5V Input, with Low IQ, 5-pin SOT (DDC), -40 to 85°C, Green (RoHS & no Sb/Br)	DDC0005A	Fitted
U18, U35	2		SN74AUP1G08DBVT	Texas Instruments	Low-Power Single 2-Input Positive-AND Gate, DBV0005A (SOT-23-5)	DBV0005A	Fitted
U33	1		CDCM1802RGTR	Texas Instruments	Clock Buffer w/Programmable Divider, LVPECL I/O + addl LVC MOS output, RGT0016A (VQFN-16)	RGT0016A	Fitted
U34, U39	2		TPS79901YZUT	Texas Instruments	Single Output High PSRR LDO, 200mA, Adjustable 1.2 to 6.5V Output, 2.7 to 6.5V Input, with Low IQ, 5-pin DSBGA (YZU), -40 to 85 °C, Green (RoHS & no Sb/Br)	YZU0005AEBC	Fitted
U36	1			Texas Instruments	Single Schmitt-Trigger Inverter, DBV0005A, LARGE T&R	DBV0005A	Fitted
U40	1		SN74AXC1T45DBVR	Texas Instruments	Single-Bit Dual-Supply Bus Transceiver, DBV0006A (SOT-23-6)	DBV0006A	Fitted

**Table 5-1. Bill of Materials (continued)**

Designator	Quantity	Value	Part Number	Manufacturer	Description	Package Reference	Fitted
U41	1		SN65LVDS100DGKR	Texas Instruments	2Gbps LVDS/LVPECL/CML to LVDS Buffer/Repeater/Translator, DGK0008A (VSSOP-8)	DGK0008A	Fitted
U42	1		SN74AUP2G79DCUR	Texas Instruments	Low-Power Dual Positive-Edge-Triggered D-Type Flip-Flop, DCU0008A (VSSOP-8)	DCU0008A	Fitted
Y1	1		SG3225VAN 200.000000M-KEGA3	Epson	Crystal Oscillator, 200MHz, LVDS, 2.5 to 3.3V, SMD	3.2x2.5mm	Fitted
Y2	1		ABM3-12.000MHZ-D2Y-T	Abracon Corporation	Crystal, 12MHz, 18pF, SMD	ABM3	Fitted
C101, C102	0	5pF	CBR04C509B1GAC	Kemet	CAP, CERM, 5pF, 100V, ±2%, C0G/NP0, 0402	0402	Not Fitted
FID1, FID2, FID3, FID4, FID5, FID6	0		N/A	N/A	Fiducial mark. There is nothing to buy or mount.	N/A	Not Fitted
R19	0	100	CRCW0402100RFKED	Vishay-Dale	RES, 100, 1%, 0.063 W, AEC-Q200 Grade 0, 0402	0402	Not Fitted
R20, R21, R22, R23, R24, R29, R173, R247, R248	0		ERJ-2GE0R00X	Panasonic	RES, 0, 5%, 0.1 W, AEC-Q200 Grade 0, 0402	0402	Not Fitted
R52, R375, R376, R377, R378, R379, R412, R413, R414, R415, R416, R417, R456, R457, R458, R459, R460, R461, R492, R493, R494, R495, R496, R497, R528, R529, R530, R531, R532, R533, R556, R557	0	1.00k	CRCW25121K00FKEG	Vishay-Dale	RES, 1.00 k, 1%, 1 W, AEC-Q200 Grade 0, 2512	2512	Not Fitted
R240, R241	0	100	ERJ-2GEJ101X	Panasonic	RES, 100, 5%, 0.1 W, AEC-Q200 Grade 0, 0402	0402	Not Fitted
R276	0	0	ERJ-2GE0R00X	Panasonic	RES, 0, 5%, 0.1 W, AEC-Q200 Grade 0, 0402	0402	Not Fitted
R283, R286	0	10k	ERJ-2GEJ103X	Panasonic	RES, 10 k, 5%, 0.1 W, AEC-Q200 Grade 0, 0402	0402	Not Fitted
U2	0		TLV75801PDBVT	Texas Instruments	Linear Voltage Regulator IC 1 Output 500mA SOT-23-5	SOT-23-5	Not Fitted

## 6 Additional Information

### 6.1 Troubleshooting

The following steps describe the ways to debug, if the EVM does not perform as expected.

1. Power supplies: Check all the power supplies and LDO voltages at the test point (See [Section 4.1.2](#)) and make sure the power supplies and LDO voltages are as expected.
2. Clock: Check the BF\_CLK\_CMOS test point and make sure that 250MHz clock is present.
3. Thermal shutdown: If the temperature of the device exceeds 110°C, then the device enters thermal shutdown, and the device functionality is disabled. TSHUT pin of the device is pulled low when this happens. This pin is connected to LED D12, and this LED glows if the device enters thermal shutdown. Reset the device to bring out of thermal shutdown.

### 6.2 Trademarks

Microsoft® and Windows® are registered trademarks of Microsoft Corporation.

All trademarks are the property of their respective owners.

## STANDARD TERMS FOR EVALUATION MODULES

1. *Delivery:* TI delivers TI evaluation boards, kits, or modules, including any accompanying demonstration software, components, and/or documentation which may be provided together or separately (collectively, an "EVM" or "EVMs") to the User ("User") in accordance with the terms set forth herein. User's acceptance of the EVM is expressly subject to the following terms.
  - 1.1 EVMs are intended solely for product or software developers for use in a research and development setting to facilitate feasibility evaluation, experimentation, or scientific analysis of TI semiconductors products. EVMs have no direct function and are not finished products. EVMs shall not be directly or indirectly assembled as a part or subassembly in any finished product. For clarification, any software or software tools provided with the EVM ("Software") shall not be subject to the terms and conditions set forth herein but rather shall be subject to the applicable terms that accompany such Software
  - 1.2 EVMs are not intended for consumer or household use. EVMs may not be sold, sublicensed, leased, rented, loaned, assigned, or otherwise distributed for commercial purposes by Users, in whole or in part, or used in any finished product or production system.
2. *Limited Warranty and Related Remedies/Disclaimers:*
  - 2.1 These terms do not apply to Software. The warranty, if any, for Software is covered in the applicable Software License Agreement.
  - 2.2 TI warrants that the TI EVM will conform to TI's published specifications for ninety (90) days after the date TI delivers such EVM to User. Notwithstanding the foregoing, TI shall not be liable for a nonconforming EVM if (a) the nonconformity was caused by neglect, misuse or mistreatment by an entity other than TI, including improper installation or testing, or for any EVMs that have been altered or modified in any way by an entity other than TI, (b) the nonconformity resulted from User's design, specifications or instructions for such EVMs or improper system design, or (c) User has not paid on time. Testing and other quality control techniques are used to the extent TI deems necessary. TI does not test all parameters of each EVM. User's claims against TI under this Section 2 are void if User fails to notify TI of any apparent defects in the EVMs within ten (10) business days after delivery, or of any hidden defects with ten (10) business days after the defect has been detected.
  - 2.3 TI's sole liability shall be at its option to repair or replace EVMs that fail to conform to the warranty set forth above, or credit User's account for such EVM. TI's liability under this warranty shall be limited to EVMs that are returned during the warranty period to the address designated by TI and that are determined by TI not to conform to such warranty. If TI elects to repair or replace such EVM, TI shall have a reasonable time to repair such EVM or provide replacements. Repaired EVMs shall be warranted for the remainder of the original warranty period. Replaced EVMs shall be warranted for a new full ninety (90) day warranty period.

### **WARNING**

**Evaluation Kits are intended solely for use by technically qualified, professional electronics experts who are familiar with the dangers and application risks associated with handling electrical mechanical components, systems, and subsystems.**

**User shall operate the Evaluation Kit within TI's recommended guidelines and any applicable legal or environmental requirements as well as reasonable and customary safeguards. Failure to set up and/or operate the Evaluation Kit within TI's recommended guidelines may result in personal injury or death or property damage. Proper set up entails following TI's instructions for electrical ratings of interface circuits such as input, output and electrical loads.**

**NOTE:**

**EXPOSURE TO ELECTROSTATIC DISCHARGE (ESD) MAY CAUSE DEGRADATION OR FAILURE OF THE EVALUATION KIT; TI RECOMMENDS STORAGE OF THE EVALUATION KIT IN A PROTECTIVE ESD BAG.**

### 3 Regulatory Notices:

#### 3.1 United States

##### 3.1.1 Notice applicable to EVMs not FCC-Approved:

**FCC NOTICE:** This kit is designed to allow product developers to evaluate electronic components, circuitry, or software associated with the kit to determine whether to incorporate such items in a finished product and software developers to write software applications for use with the end product. This kit is not a finished product and when assembled may not be resold or otherwise marketed unless all required FCC equipment authorizations are first obtained. Operation is subject to the condition that this product not cause harmful interference to licensed radio stations and that this product accept harmful interference. Unless the assembled kit is designed to operate under part 15, part 18 or part 95 of this chapter, the operator of the kit must operate under the authority of an FCC license holder or must secure an experimental authorization under part 5 of this chapter.

##### 3.1.2 For EVMs annotated as FCC – FEDERAL COMMUNICATIONS COMMISSION Part 15 Compliant:

#### **CAUTION**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### **FCC Interference Statement for Class A EVM devices**

*NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.*

#### **FCC Interference Statement for Class B EVM devices**

*NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:*

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### 3.2 Canada

##### 3.2.1 For EVMs issued with an Industry Canada Certificate of Conformance to RSS-210 or RSS-247

#### **Concerning EVMs Including Radio Transmitters:**

This device complies with Industry Canada license-exempt RSSs. Operation is subject to the following two conditions:

(1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

#### **Concernant les EVMs avec appareils radio:**

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

#### **Concerning EVMs Including Detachable Antennas:**

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication. This radio transmitter has been approved by Industry Canada to operate with the antenna types listed in the user guide with the maximum permissible gain and required antenna impedance for each antenna type indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

### Concernant les EVMs avec antennes détachables

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante. Le présent émetteur radio a été approuvé par Industrie Canada pour fonctionner avec les types d'antenne énumérés dans le manuel d'usage et ayant un gain admissible maximal et l'impédance requise pour chaque type d'antenne. Les types d'antenne non inclus dans cette liste, ou dont le gain est supérieur au gain maximal indiqué, sont strictement interdits pour l'exploitation de l'émetteur.

#### 3.3 Japan

3.3.1 *Notice for EVMs delivered in Japan:* Please see [http://www.tij.co.jp/lstds/ti\\_ja/general/eStore/notice\\_01.page](http://www.tij.co.jp/lstds/ti_ja/general/eStore/notice_01.page) 日本国内に輸入される評価用キット、ボードについては、次のところをご覧ください。

<https://www.ti.com/ja-jp/legal/notice-for-evaluation-kits-delivered-in-japan.html>

3.3.2 *Notice for Users of EVMs Considered "Radio Frequency Products" in Japan:* EVMs entering Japan may not be certified by TI as conforming to Technical Regulations of Radio Law of Japan.

If User uses EVMs in Japan, not certified to Technical Regulations of Radio Law of Japan, User is required to follow the instructions set forth by Radio Law of Japan, which includes, but is not limited to, the instructions below with respect to EVMs (which for the avoidance of doubt are stated strictly for convenience and should be verified by User):

1. Use EVMs in a shielded room or any other test facility as defined in the notification #173 issued by Ministry of Internal Affairs and Communications on March 28, 2006, based on Sub-section 1.1 of Article 6 of the Ministry's Rule for Enforcement of Radio Law of Japan,
2. Use EVMs only after User obtains the license of Test Radio Station as provided in Radio Law of Japan with respect to EVMs, or
3. Use of EVMs only after User obtains the Technical Regulations Conformity Certification as provided in Radio Law of Japan with respect to EVMs. Also, do not transfer EVMs, unless User gives the same notice above to the transferee. Please note that if User does not follow the instructions above, User will be subject to penalties of Radio Law of Japan.

【無線電波を送信する製品の開発キットをお使いになる際の注意事項】 開発キットの中には技術基準適合証明を受けていないものがあります。技術適合証明を受けていないものご使用に際しては、電波法遵守のため、以下のいずれかの措置を取っていただく必要がありますのでご注意ください。

1. 電波法施行規則第6条第1項第1号に基づく平成18年3月28日総務省告示第173号で定められた電波暗室等の試験設備でご使用いただく。
2. 実験局の免許を取得後ご使用いただく。
3. 技術基準適合証明を取得後ご使用いただく。

なお、本製品は、上記の「ご使用にあたっての注意」を譲渡先、移転先に通知しない限り、譲渡、移転できないものとします。

上記を遵守頂けない場合は、電波法の罰則が適用される可能性があることをご留意ください。日本テキサス・イ

ンスツルメンツ株式会社

東京都新宿区西新宿 6 丁目 2 4 番 1 号

西新宿三井ビル

3.3.3 *Notice for EVMs for Power Line Communication:* Please see [http://www.tij.co.jp/lstds/ti\\_ja/general/eStore/notice\\_02.page](http://www.tij.co.jp/lstds/ti_ja/general/eStore/notice_02.page)

電力線搬送波通信についての開発キットをお使いになる際の注意事項については、次のところをご覧ください。 <https://www.ti.com/ja-jp/legal/notice-for-evaluation-kits-for-power-line-communication.html>

#### 3.4 European Union

3.4.1 *For EVMs subject to EU Directive 2014/30/EU (Electromagnetic Compatibility Directive):*

This is a class A product intended for use in environments other than domestic environments that are connected to a low-voltage power-supply network that supplies buildings used for domestic purposes. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

- 
4. *EVM Use Restrictions and Warnings:*
    - 4.1 EVMS ARE NOT FOR USE IN FUNCTIONAL SAFETY AND/OR SAFETY CRITICAL EVALUATIONS, INCLUDING BUT NOT LIMITED TO EVALUATIONS OF LIFE SUPPORT APPLICATIONS.
    - 4.2 User must read and apply the user guide and other available documentation provided by TI regarding the EVM prior to handling or using the EVM, including without limitation any warning or restriction notices. The notices contain important safety information related to, for example, temperatures and voltages.
    - 4.3 *Safety-Related Warnings and Restrictions:*
      - 4.3.1 User shall operate the EVM within TI's recommended specifications and environmental considerations stated in the user guide, other available documentation provided by TI, and any other applicable requirements and employ reasonable and customary safeguards. Exceeding the specified performance ratings and specifications (including but not limited to input and output voltage, current, power, and environmental ranges) for the EVM may cause personal injury or death, or property damage. If there are questions concerning performance ratings and specifications, User should contact a TI field representative prior to connecting interface electronics including input power and intended loads. Any loads applied outside of the specified output range may also result in unintended and/or inaccurate operation and/or possible permanent damage to the EVM and/or interface electronics. Please consult the EVM user guide prior to connecting any load to the EVM output. If there is uncertainty as to the load specification, please contact a TI field representative. During normal operation, even with the inputs and outputs kept within the specified allowable ranges, some circuit components may have elevated case temperatures. These components include but are not limited to linear regulators, switching transistors, pass transistors, current sense resistors, and heat sinks, which can be identified using the information in the associated documentation. When working with the EVM, please be aware that the EVM may become very warm.
      - 4.3.2 EVMs are intended solely for use by technically qualified, professional electronics experts who are familiar with the dangers and application risks associated with handling electrical mechanical components, systems, and subsystems. User assumes all responsibility and liability for proper and safe handling and use of the EVM by User or its employees, affiliates, contractors or designees. User assumes all responsibility and liability to ensure that any interfaces (electronic and/or mechanical) between the EVM and any human body are designed with suitable isolation and means to safely limit accessible leakage currents to minimize the risk of electrical shock hazard. User assumes all responsibility and liability for any improper or unsafe handling or use of the EVM by User or its employees, affiliates, contractors or designees.
    - 4.4 User assumes all responsibility and liability to determine whether the EVM is subject to any applicable international, federal, state, or local laws and regulations related to User's handling and use of the EVM and, if applicable, User assumes all responsibility and liability for compliance in all respects with such laws and regulations. User assumes all responsibility and liability for proper disposal and recycling of the EVM consistent with all applicable international, federal, state, and local requirements.
  5. *Accuracy of Information:* To the extent TI provides information on the availability and function of EVMs, TI attempts to be as accurate as possible. However, TI does not warrant the accuracy of EVM descriptions, EVM availability or other information on its websites as accurate, complete, reliable, current, or error-free.
  6. *Disclaimers:*
    - 6.1 EXCEPT AS SET FORTH ABOVE, EVMS AND ANY MATERIALS PROVIDED WITH THE EVM (INCLUDING, BUT NOT LIMITED TO, REFERENCE DESIGNS AND THE DESIGN OF THE EVM ITSELF) ARE PROVIDED "AS IS" AND "WITH ALL FAULTS." TI DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, REGARDING SUCH ITEMS, INCLUDING BUT NOT LIMITED TO ANY EPIDEMIC FAILURE WARRANTY OR IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF ANY THIRD PARTY PATENTS, COPYRIGHTS, TRADE SECRETS OR OTHER INTELLECTUAL PROPERTY RIGHTS.
    - 6.2 EXCEPT FOR THE LIMITED RIGHT TO USE THE EVM SET FORTH HEREIN, NOTHING IN THESE TERMS SHALL BE CONSTRUED AS GRANTING OR CONFERRING ANY RIGHTS BY LICENSE, PATENT, OR ANY OTHER INDUSTRIAL OR INTELLECTUAL PROPERTY RIGHT OF TI, ITS SUPPLIERS/LICENSORS OR ANY OTHER THIRD PARTY, TO USE THE EVM IN ANY FINISHED END-USER OR READY-TO-USE FINAL PRODUCT, OR FOR ANY INVENTION, DISCOVERY OR IMPROVEMENT, REGARDLESS OF WHEN MADE, CONCEIVED OR ACQUIRED.
  7. *USER'S INDEMNITY OBLIGATIONS AND REPRESENTATIONS.* USER WILL DEFEND, INDEMNIFY AND HOLD TI, ITS LICENSORS AND THEIR REPRESENTATIVES HARMLESS FROM AND AGAINST ANY AND ALL CLAIMS, DAMAGES, LOSSES, EXPENSES, COSTS AND LIABILITIES (COLLECTIVELY, "CLAIMS") ARISING OUT OF OR IN CONNECTION WITH ANY HANDLING OR USE OF THE EVM THAT IS NOT IN ACCORDANCE WITH THESE TERMS. THIS OBLIGATION SHALL APPLY WHETHER CLAIMS ARISE UNDER STATUTE, REGULATION, OR THE LAW OF TORT, CONTRACT OR ANY OTHER LEGAL THEORY, AND EVEN IF THE EVM FAILS TO PERFORM AS DESCRIBED OR EXPECTED.
-

8. *Limitations on Damages and Liability:*

8.1 *General Limitations.* IN NO EVENT SHALL TI BE LIABLE FOR ANY SPECIAL, COLLATERAL, INDIRECT, PUNITIVE, INCIDENTAL, CONSEQUENTIAL, OR EXEMPLARY DAMAGES IN CONNECTION WITH OR ARISING OUT OF THESE TERMS OR THE USE OF THE EVMS , REGARDLESS OF WHETHER TI HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. EXCLUDED DAMAGES INCLUDE, BUT ARE NOT LIMITED TO, COST OF REMOVAL OR REINSTALLATION, ANCILLARY COSTS TO THE PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES, RETESTING, OUTSIDE COMPUTER TIME, LABOR COSTS, LOSS OF GOODWILL, LOSS OF PROFITS, LOSS OF SAVINGS, LOSS OF USE, LOSS OF DATA, OR BUSINESS INTERRUPTION. NO CLAIM, SUIT OR ACTION SHALL BE BROUGHT AGAINST TI MORE THAN TWELVE (12) MONTHS AFTER THE EVENT THAT GAVE RISE TO THE CAUSE OF ACTION HAS OCCURRED.

8.2 *Specific Limitations.* IN NO EVENT SHALL TI'S AGGREGATE LIABILITY FROM ANY USE OF AN EVM PROVIDED HEREUNDER, INCLUDING FROM ANY WARRANTY, INDEMNITY OR OTHER OBLIGATION ARISING OUT OF OR IN CONNECTION WITH THESE TERMS, , EXCEED THE TOTAL AMOUNT PAID TO TI BY USER FOR THE PARTICULAR EVM(S) AT ISSUE DURING THE PRIOR TWELVE (12) MONTHS WITH RESPECT TO WHICH LOSSES OR DAMAGES ARE CLAIMED. THE EXISTENCE OF MORE THAN ONE CLAIM SHALL NOT ENLARGE OR EXTEND THIS LIMIT.

9. *Return Policy.* Except as otherwise provided, TI does not offer any refunds, returns, or exchanges. Furthermore, no return of EVM(s) will be accepted if the package has been opened and no return of the EVM(s) will be accepted if they are damaged or otherwise not in a resalable condition. If User feels it has been incorrectly charged for the EVM(s) it ordered or that delivery violates the applicable order, User should contact TI. All refunds will be made in full within thirty (30) working days from the return of the components(s), excluding any postage or packaging costs.

10. *Governing Law:* These terms and conditions shall be governed by and interpreted in accordance with the laws of the State of Texas, without reference to conflict-of-laws principles. User agrees that non-exclusive jurisdiction for any dispute arising out of or relating to these terms and conditions lies within courts located in the State of Texas and consents to venue in Dallas County, Texas. Notwithstanding the foregoing, any judgment may be enforced in any United States or foreign court, and TI may seek injunctive relief in any United States or foreign court.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265  
Copyright © 2023, Texas Instruments Incorporated

## IMPORTANT NOTICE AND DISCLAIMER

TI PROVIDES TECHNICAL AND RELIABILITY DATA (INCLUDING DATA SHEETS), DESIGN RESOURCES (INCLUDING REFERENCE DESIGNS), APPLICATION OR OTHER DESIGN ADVICE, WEB TOOLS, SAFETY INFORMATION, AND OTHER RESOURCES "AS IS" AND WITH ALL FAULTS, AND DISCLAIMS ALL WARRANTIES, EXPRESS AND IMPLIED, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

These resources are intended for skilled developers designing with TI products. You are solely responsible for (1) selecting the appropriate TI products for your application, (2) designing, validating and testing your application, and (3) ensuring your application meets applicable standards, and any other safety, security, regulatory or other requirements.

These resources are subject to change without notice. TI grants you permission to use these resources only for development of an application that uses the TI products described in the resource. Other reproduction and display of these resources is prohibited. No license is granted to any other TI intellectual property right or to any third party intellectual property right. TI disclaims responsibility for, and you will fully indemnify TI and its representatives against, any claims, damages, costs, losses, and liabilities arising out of your use of these resources.

TI's products are provided subject to [TI's Terms of Sale](#) or other applicable terms available either on [ti.com](https://www.ti.com) or provided in conjunction with such TI products. TI's provision of these resources does not expand or otherwise alter TI's applicable warranties or warranty disclaimers for TI products.

TI objects to and rejects any additional or different terms you may have proposed.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265

Copyright © 2025, Texas Instruments Incorporated