

BOOSTXL-DRV8304H EVM User's Guide

This document is provided with the BOOSTXL-DRV8304H customer evaluation module (EVM) as a supplement to the [DRV8304 38-V Three-Phase Smart Gate Driver data sheet](#). The scope of this document is to provide the user with a guide to evaluate the DRV8304 device with the MSP430F5529 LaunchPad™ development kit.

Contents

1	Overview	2
1.1	Purpose and Scope	2
2	Hardware and Software Overview	3
2.1	Hardware Overview.....	3
2.2	Software and Tools Overview	8

List of Figures

1	LaunchPad™ and BOOSTXL-DRV8304H EVM.....	2
2	Hardware Connections Overview.....	3
3	Connections Overview	4
4	BOOSTXL-DRV8304H Jumper Connectors Pinout	5
5	EVM Showing the Position of LEDs.....	6
6	Downloaded Executable for Code Composer Studio Installation	9
7	CCS License Agreement	9
8	Default Installation Location for CCS	9
9	Processors Supported by CCS.....	10
10	Components Available for Installation	10
11	Emulators Available for Installation	11
12	DRV8304 Firmware Installer Executable File	11
13	Language Selection.....	11
14	Setup Home Screen	12
15	DRV8304 Software License Agreement	12
16	Setup Destination Folder	13
17	Select DRV8304 Setup Components.....	13
18	Warning Message to Close CCS.....	14
19	Firmware Setup Complete	14
20	Open CCS Application.....	15
21	Workspace Selection	15
22	Importing CSS Project.....	16
23	Select Projects to Import	16
24	Project Explorer	17
25	Build and Debug.....	17
26	Run and Pause Debug Session.....	17
27	New CCS Project.....	18
28	Error Initializing Emulator	19

29	Updating LaunchPad™ Development Kit Firmware	19
30	TI MSP430 USB Installer.....	20
31	BOOSTXL-DRV8304X EVM Device Launch	21

List of Tables

1	BOOSTXL-DRV8304H J4 Pin Connections.....	7
2	BOOSTXL-DRV8304H J5 Pin Connections.....	8
3	Hall Sensor Signal Connections to the BOOSTXL-DRV8304H EVM.....	8

Trademarks

LaunchPad, MSP430, Code Composer Studio, BoosterPack are trademarks of Texas Instruments. Microsoft, Windows are registered trademarks of Microsoft Corporation. All other trademarks are the property of their respective owners.

1 Overview

The BOOSTXL-DRV8304H evaluation module (EVM) is an application board designed to allow easy evaluation of the DRV8304 device. The DRV8304 device is a gate driver IC for three-phase motor drive applications. The DRV8304 device provides three high-accuracy trimmed and temperature-compensated half bridge drivers, each capable of driving a high-side and low-side N-type MOSFET.

The DRV8304 device is used in motor control applications that require a high degree of integrated protection, diagnosis, and monitoring. Both SPI (DRV8304S) and hardware (DRV8304H) interface variants provide detailed fault reporting and flexible parameter settings such as current control options for slew-rate control of the gate drivers and various protection features.

This EVM uses a compact and modular form factor for ease of use and is designed to dock with compatible Texas Instruments LaunchPad development kits, or other MCUs for a complete motor-control system. Along with the hardware of the DRV8304 device, the MSP430F5529 microcontroller has loaded reference software that provide the necessary gating pulses to the DRV8304 device to control BLDC motors.




Figure 1. LaunchPad™ and BOOSTXL-DRV8304H EVM

1.1 Purpose and Scope

This document is designed to be used as a startup guide and to supplement the DRV8304 and MSP430F5529 BLDC motor control demo code kit. This document is intended for the engineers involved in the design, implementation, and validation of DRV8304x and MSP430F5529 reference software.

The scope of this document is to provide the user with a guide to evaluate the DRV8304 device with an MSP430F5529 LaunchPad development kit. This document covers the hardware (HW) connections required between the BOOSTXL-DRV8304H EVM and LaunchPad development kit. When the HW connections are done, the user is required to download the required tools and software (SW) to spin the motor. The following sections provide step-by-step details on the installing the CCS tool, importing the DRV8304 project into CCS, building the project, debugging the project, and spinning the motor, see [Section 2.2](#).

This reference SW comprises trapezoidal sensed and sensorless algorithms for BLDC motor control. For additional information on the algorithms used, refer to [BOOSTXL-DRV8304x Sensed Software User's Guide](#) and [BOOSTXL-DRV8304x Sensorless Software User's Guide](#).

2 Hardware and Software Overview

2.1 Hardware Overview

2.1.1 Features

The following lists the BOOSTXL-DRV8304H EVM features:

- Operating supply range from 6 V to 38 V
- Three CSD88584Q5DC N-channel NexFETs driven by the gate driver
- Protected phase voltages provided to header pins through a voltage divider
- Connector available for Hall sensor inputs connected to the MSP430™ MCU. The 3.3-V supply to the Hall sensors is derived by the LMR16006XDDCR buck converter
- Includes sample code for MSP430F5529 LaunchPad

2.1.2 BOOSTXL-DRV8304H EVM Overview

Figure 2 shows the major blocks of the hardware on the BOOSTXL-DRV8304H EVM.





Figure 2. Hardware Connections Overview

- **Power Supply (J1):** valid input supply voltages from 6 V to 38 V from a battery or a DC voltage source.
- **DRV8304 (U3):** 3-phase automotive gate driver with three integrated current shunt amplifiers.
- **Drive Stage (U1, U2, U5):** 3x CSD88584Q5DC N-channel NexFETs driven by the gate driver.
- **LMR16006 (U4):** DC/DC buck regulator with 3.3-V output used to support external hall sensors, not required for device operation.
- **To Motor (J2):** switching nodes of the 3-phase bridges for motor connection.
- **LEDs (3P3V[D4], nFault[D1]):** shows the status of the board.



2.1.3 Pinout and Jumper Overview

Figure 3 shows the various jumper labels on the BOOSTXL-DRV8304H EVM.




Figure 3. Connections Overview

Figure 4 shows the various jumper connection pinouts from the BOOSTXL-DRV8304H EVM to the MCU.




Figure 4. BOOSTXL-DRV8304H Jumper Connectors Pinout

2.1.4 Connecting the BOOSTXL-DRV8304H EVM to the LaunchPad™

Follow these steps when connecting the BOOSTXL-DRV8304H EVM to the LaunchPad

- Step 1. Make sure nothing is connected to the board, and no power is being supplied.
- Step 2. Connect the BOOSTXL-DRV8304H connectors J1/J3 and J2/J4, onto the MSP430F5529 LaunchPad development kit (see Figure 1).
- Step 3. Connect a USB cable to the PC and directly to the MSP430F5529 LaunchPad development kit.
- Step 4. Connect the three phases of the BLDC motor to the three-phase motor socket, J2 (the pins are labeled A, B, and C), provided on the BOOSTXL-DRV8304H EVM board (see Figure 3).

CAUTION



Make sure the proper orientation is used, and verify that all pins make proper contact between the boards before powering on.

- Step 5. Connect the supply voltage ranging from 6 V to 38 V from a battery or a DC-voltage source to

the voltage supply pin, J1.

- Step 6. Confirm that the 3P3V LED is turned on and the nFAULT LED turned off after powering the device (see [Figure 5](#)).




Figure 5. EVM Showing the Position of LEDs

2.1.5 Hardware, Software, and Tools Required for Evaluation

The software, hardware, and tools required to optimally evaluate the reference software code with the BOOSTXL-DRV8304H EVM are listed as follows:

- BOOSTXL-DRV8304H EVM
- MSP430F5529 LaunchPad development kit
- Voltage supply from 6 V to 38 V
- Code Composer Studio™ software V.6.1 and above
- BOOSTXL-DRV8304H reference software development package
- BOOSTXL-DRV8304H GUI software

2.1.6 Interfacing DRV8304x and MSP430F5529 LaunchPad™

The DRV8304 device has 40 pins with different functions. These pins are interfaced with the MSP430F5529XL LaunchPad development kit which is mapped appropriately to receive the functionality of the BoosterPack™ plug-in module. These 40 pins are grouped into 4 ports. [Table 1](#) and [Table 2](#) list the interfacing of these ports with the MSP430F5529 device.

Table 1. BOOSTXL-DRV8304H J4 Pin Connections

J4 Pin Number	BOOSTXL-DRV8304H Function	MSP430F5529 Function	Description
1	INHA	P2.5, TA2.2	Secondary function, Timer 2 comparator output to generate PWM for A phase high-side switches
2	GND	GND	ADC GND connections
3	INLA	P2.4, TA2.1	Secondary function, Timer 2 comparator output to generate PWM for A phase low-side switches
4	HALLA	P2.0, SPI enable	Hall sensor A from motor
5	INHB	P1.5, TA0.4	Secondary function, Timer 1 comparator output to generate PWM for B phase high-side switches
6	HALLB	P2.2, I/O PIN with Interrupt	Hall sensor B from motor
7	INLB	P1.4, TA0.3	Secondary function, Timer 1 comparator output to generate PWM for B phase low-side switches
8	No function	P7.4, I/O pin	No function
9	INHC	P1.3, TA0.2	Secondary function, Timer 1 comparator output to generate PWM for C phase high-side switches
10	No function	RST	No function
11	INLC	P1.2, TA0.1	Secondary function, Timer 1 comparator output to generate PWM for C phase low-side switches
12	SDI	P3.0, UCBSIMO	Secondary function for data input to DRV8304S
13	MODE	P4.3, I/O pin	Sets the input control mode, 4-level input pin (DRV8304H devices only)
14	SDO	P3.1, UCBSOMI	Secondary function for data output from DRV8304S
15	LED	P4.0, I/O pin	Visual feedback for faults.
16	HALLC	P2.6, I/O pin With Interrupt	Hall sensor C from motor enable the gate driver and current shunt amplifiers
17	SHUNT	P3.7, I/O pin	This pin is pulled high for 3 shunt variant and pulled low for single shunt variant
18	nSCS/GAIN	P2.2, I/O PIN with Interrupt	Active low enables serial interface communication and sets the gain of the shunt amplifiers, 4-level input pin (DRV8304H devices only)
19	VARIANT	P8.2, I/O pin	Pulled low for DRV8304H, high for DRV8304S devices
20	CAL	P8.1, I/O pin	Pull logic high to internally short all amplifier inputs together

Table 2. BOOSTXL-DRV8304H J5 Pin Connections

J5 Pin Number	BOOSTXL-DRV8304H Function	MSP430F5529 Function	Description
1	3.3 V	3.3 V	3.3-V LaunchPad supply
2	No function	5 V	5-V supply
3	VSENV M	P6.5, ADC channel – A5	Sensing VCC supply voltage
4	GND	GND	ADC - GND connections
5	No function	P3.4, I/O PIN	Software debug pins (optional)
6	VSENA	P6.0, ADC channel – 0	Sensing A phase voltage
7	No function	P3.3, I/O PIN	Software debug pins (optional)
8	VSENB	P6.1, ADC channel – 1	Sensing B phase voltage
9	ENABLE	P1.6, I/O pin with Interrupt	Logic low to enter a low-power sleep mode
10	VSENC	P6.2, ADC channel – 2	Sensing C phase voltage
11	POT	P6.6, ADC channel – A6	Optional POT to vary the voltage 0-3.3 V on pin
12	ISENC	P6.3, ADC channel – 3	Sensing C phase current
13	SCLK	P3.2, UCBOCLK – SPI CLK	Secondary function for pin SPI CLK
14	ISENB	P6.4, ADC channel – 4	Sensing B phase current
15	nFAULT	P2.7, I/O pin with Interrupt	Pulled logic low during a fault condition
16	ISENA	P7.0, ADC channel – 12	Sensing A phase current
17	No function	P4.2, I/O pin	Software debug pins (optional)
18	IDRIVE	P3.6, I/O pin	Sets gate drive peak current, 7-level input pin (DRV8304H devices only)
19	No function	P4.1, I/O pin	Software debug pins (optional)
20	VDS	P3.5, I/O pin	Sets VDS monitor threshold voltage, 7-level input pin (DRV8304H devices only)

2.1.7 Hardware Connections for Hall Sensor Operation

Table 3 lists the signal connections from the Hall sensor of the motor connected to jumper J3 on the BOOSTXL-DRV8304H EVM.

Table 3. Hall Sensor Signal Connections to the BOOSTXL-DRV8304H EVM

Signal Description	Equivalent on BOOSTXL-DRV8304H EVM
GND	J3-1(-)
Hall C	J3-2(C)
Hall B	J3-3(B)
Hall A	J3-4(A)
V3P3	J3-5(+)

2.2 Software and Tools Overview

2.2.1 Installing CCS for Software Evaluation

Code Composer Studio (CCS) versions 5.x.x and 6.x.x were used and tested for DRV8304X reference code. Install an authorized version from www.ti.com/tool/ccstudio.

NOTE: A myTI login account is required to download CCS as well as the SDK package. This section describes the installation procedure for CCS5.4; however, installing other versions of CCS v5.x, including CCS, v6.x is similar.

After following the required steps to download the CCS installer, the `ccs_setup_5.4.0.00091.exe` file should be located in the specified download directory. [Figure 6](#) shows this file.



Figure 6. Downloaded Executable for Code Composer Studio Installation

Follow the installation process listed:

- Step 1. Run the installer by double clicking the `ccs_setup_win32.exe` file.
- Step 2. Read through and accept the license agreement to proceed with the installation (see [Figure 7](#)).




Figure 7. CCS License Agreement

- Step 3. Choose a destination directory. Using the default (`c:\ti`) removes a step in the SDK installation procedure (see [Figure 8](#)).




Figure 8. Default Installation Location for CCS

- Step 4. Choose the processor architectures to install (see [Figure 9](#)).
For the DRV83xx, the MSP430 and C28x are the only needed processor packages. The compiler tools

are required. Ensure that the box for the *TI MSP430 Compiler Tool* is checked.




Figure 9. Processors Supported by CCS

Step 5. Select the emulator components to install.

For the provided tool, the MSP430 USB FET emulator is required.

Step 6. Review the installation size and click the *Finish* button to begin installation of the CCS software (see [Figure 10](#)).




Figure 10. Components Available for Installation

- Step 7. Choose add-on software (this step is optional).
- Step 8. Review the installation and click the *Finish* button to finalize (see [Figure 11](#)).



Figure 11. Emulators Available for Installation

- Step 9. After the installation is complete, click the *Finish* button to exit the set-up.

2.2.2 Installing DRV8304 Reference Software Development Package

The DRV8304 reference software contains the files required to program DRV8304 devices along with the MSP430F5529 using CCS v5.x or CCS v6.x. All of these files are included in the installation package. To access this package, contact the DRV8x applications team or the respective field-sales engineer.

Install the reference software development package using these steps:

- Step 1. Double click the executable file (.exe) for the DRV8304 reference software installer (see [Figure 12](#)).




Figure 12. DRV8304 Firmware Installer Executable File

- Step 2. Follow the prompts to select another language from the default of English (see [Figure 13](#)).




Figure 13. Language Selection

Step 3. Click the *Next* button on the DRV8304 installer welcome screen (see [Figure 14](#)).




Figure 14. Setup Home Screen

Step 4. Read through and accept the license agreement to proceed with the installation (see [Figure 15](#)).



Figure 15. DRV8304 Software License Agreement

- Step 5. Choose the destination location for the example CCS projects and the documentation (see [Figure 16](#)). This destination can be set to any location in the PC.




Figure 16. Setup Destination Folder

- Step 6. Select each DRV83x component to install (see [Figure 17](#)).




Figure 17. Select DRV8304 Setup Components

Step 7. Ensure all running instances of CCS are closed (see [Figure 18](#)).




Figure 18. Warning Message to Close CCS

Step 8. Continue with the installation process.

Step 9. Click the *Next* button to install after reviewing the settings.

Step 10. Click the *Finish* button when the files are successfully installed in the destination folder (see [Figure 19](#)).




Figure 19. Firmware Setup Complete

2.2.3 Creating or Importing a DRV8304 Project Into CCS

When the CCS software is started, the user must first select a workspace. A workspace is the structure in which projects are kept. Multiple projects can be saved in one workspace. After importing an existing project, the user can explore the features of CCS to become familiar with the IDE. Follow these steps to import the provided project:

- Step 1. Double click the CCS icon to open the application. A CCS icon is placed on the desktop after installation.




Figure 20. Open CCS Application

- Step 2. Select the location and name of the workspace. The location and naming convention can be changed. (see [Figure 21](#)).
- Step 3. Click the *OK* button to accept.




Figure 21. Workspace Selection

After selecting the workspace, the CCS software opens displaying a welcome menu.

- Step 4. Import a project either from the welcome menu by selecting *Import Project* or go to the *Project* menu and select *Import Existing CCS Eclipse Project* (see [Figure 22](#)).




Figure 22. Importing CSS Project

- Step 5. In the new window that appears showing the import options, click the *Browse...* button and find the provided projects through the folder browser. These projects are located in the SDK installation directory. The default location of the root folder is under C:\ti (see [Figure 23](#)). When selected, the provided project appears under *Discovered Projects*.
- Step 6. Make sure the correct box is checked and then click the *Finish* button (see [Figure 23](#)).




Figure 23. Select Projects to Import

When the projects are imported to the workspace, the project should appear in the *Project Explorer* window as shown in [Figure 24](#).




Figure 24. Project Explorer

Step 7. Explore the project files, build the project to create an image to be downloaded on the MSP430F5529 hardware, and download the project from here. Make sure the MSP430F5529 is connected to the PC through USB interface before downloading the code.




Figure 25. Build and Debug

Step 8. When the CCS software is connected to the device, run the program from CCS to execute the program in hardware by clicking the green play button (see [Figure 26](#)). Click the red stop button (see [Figure 26](#)) to disconnect from the device debugger.




Figure 26. Run and Pause Debug Session

- Step 9. Start a new project by clicking on the *File* menu, selecting *New*, and then *CCS Project*. A new window appears. Complete these steps to proceed:
1. Fill in the *Project Name* text field.
 2. Under the *Family* drop-down menu, select *MSP430x5xx*.
 3. Select *MSP430F5529* from the *Variant* drop-down menu and the specific device in the adjoining field.




Figure 27. New CCS Project

2.2.4 Updating the MSP430 USB-FET

After the reference project is imported and selected in the CCS software, the provided software builds and runs on the MSP430 device. The device is programmed by the MSP430 USB-FET. When this device is used, the CCS software automatically detects the firmware version and notifies of an update. The process takes a few minutes, let the update finish before unplugging the USB cable or closing CCS. [Figure 28](#) and [Figure 29](#) show the update process.

CAUTION

To help prevent any device damage, wait for the update to finish before unplugging the MSP430 device or closing CCS.




Figure 28. Error Initializing Emulator




Figure 29. Updating LaunchPad™ Development Kit Firmware

2.2.5 GUI Application

2.2.5.1 Installation

Follow these steps to install the GUI application:

- Step 1. Download and run the *Setup_DRV8304x-0.9.0_EVM.exe* installer file to install the GUI application.
- Step 2. Install the COM port driver for *TI MSP430 USB* (the firmware on MSP430F5529 LaunchPad development kit plug-in module).

This driver is automatically installed during the GUI installation process. Click the *Install* button when the window shown in [Figure 30](#) appears during the GUI installation. If this pop-up does not appear, then the drivers are already installed.




Figure 30. TI MSP430 USB Installer

If the automatic driver installation fails for some reason, or if the *Don't Install* button was clicked, install the drivers manually. First, find the driver .inf file (*mcp430_ti_signed.inf*) in the following folder: C:\Program Files (x86)\Texas Instruments\DRV8304x\TI MSP430 USB Driver. Right click on the .inf file and select the *Install* option. Follow the installation instructions to successfully install the driver.

If any issues occur during the driver installation steps or to learn more about the process, download and extract the *MSP430 USB Developers Package* from www.ti.com/tool/mcp430usbdevpack and refer to the Microsoft® Windows® 7 and Windows 8 sections in the document *Examples_Guide_MSP430_USB.pdf*, based on the appropriate Windows. This document is found under the *MSP430USBDevelopersPackage_5_10_00_17\MSP430_USB_Software\Documentation* directory of the extracted *MSP430 USB Developers Package*.

2.2.5.2 Hardware Setup

The hardware required to run the motor control is an MSP430F5529 LaunchPad development kit, the BOOSTXL-DRV8304x BoosterPack plug-in module, a micro-USB cable, and a power supply with a DC output from 6 to 38 V. Follow these steps to start up the BoosterPack plug-in module:

- Step 1. Dock the BOOSTXL-DRV8304x BoosterPack plug-in module to the MSP430F5529 LaunchPad development kit through the two 40-pin headers J4 and J5.

NOTE: Observe the correct polarity of the 40-pin LaunchPad headers. The MSP430F5529 LaunchPad header J1 should be connected to BOOSTXL-DRV8304x BoosterPack header J5 and MSP430F5529 LaunchPad header J2 should be connected to BOOSTXL-DRV8304x BoosterPack header J4.

- Step 2. Connect the three phases from the brushless DC motor to the J2 connector on the BOOSTXL-DRV8304x BoosterPack plug-in module. Phase A, B, and C are labeled in white silkscreen on the PCB top layer.

NOTE: If using the sensed firmware on the MSP430F5529 LaunchPad development kit, connect a brushless DC motor Hall sensor input to header J3. If using sensorless firmware, header J3 can be left unconnected.

NOTE: If using 1x PWM Mode with the **sensored firmware** R35, R36, and R37 must be populated with 0-Ω resistors.

Step 3. Connect the DC power supply to header J1.

NOTE: Observe the correct polarity of +VM and GND connections on the BOOSTXL-DRV8304x BoosterPack connection J1

Step 4. Connect a micro-USB cable to the LaunchPad development kit and computer.

Step 5. Turn on the power supply and power up the PCB.

2.2.5.3 Launching **BOOSTXL-DRV8304X EVM GUI**

The BOOSTXL-DRV8304X EVM GUI facilitates the control of brushless DC motors. The BOOSTXL-DRV8304x GUI provides functionality for adjusting the speed and direction of the motor, setting various fault parameters such as voltage and current-protection limits, observing the motor drive speed, and monitoring the device fault status. The GUI can also be used to tune the motor for best performance using various parameters available in the motor control parameter page.

To launch the GUI, click on the BOOSTXL-DRV8304x EVM shortcut on the desktop or navigate to the Windows Start Menu and click *All Programs*. Navigate to the *Texas Instruments* folder and select the BOOSTXL-DRV8304x folder.

The *Device Launch* page (see [Figure 31](#)) is displayed to launch one of the 2 device variants (DRV8304S, DRV8304H). Click on one of the *Launch* buttons to launch either the **DRV8304S** or **DRV8304H** labels.

For a guide on the different attributes of the BOOSTXL-DRV8304x EVM GUI, refer to the [BOOSTXL-DRV8304x GUI User's Guide](#).




Figure 31. BOOSTXL-DRV8304X EVM Device Launch

IMPORTANT NOTICE FOR TI DESIGN INFORMATION AND RESOURCES

Texas Instruments Incorporated ("TI") technical, application or other design advice, services or information, including, but not limited to, reference designs and materials relating to evaluation modules, (collectively, "TI Resources") are intended to assist designers who are developing applications that incorporate TI products; by downloading, accessing or using any particular TI Resource in any way, you (individually or, if you are acting on behalf of a company, your company) agree to use it solely for this purpose and subject to the terms of this Notice.

TI's provision of TI Resources does not expand or otherwise alter TI's applicable published warranties or warranty disclaimers for TI products, and no additional obligations or liabilities arise from TI providing such TI Resources. TI reserves the right to make corrections, enhancements, improvements and other changes to its TI Resources.

You understand and agree that you remain responsible for using your independent analysis, evaluation and judgment in designing your applications and that you have full and exclusive responsibility to assure the safety of your applications and compliance of your applications (and of all TI products used in or for your applications) with all applicable regulations, laws and other applicable requirements. You represent that, with respect to your applications, you have all the necessary expertise to create and implement safeguards that (1) anticipate dangerous consequences of failures, (2) monitor failures and their consequences, and (3) lessen the likelihood of failures that might cause harm and take appropriate actions. You agree that prior to using or distributing any applications that include TI products, you will thoroughly test such applications and the functionality of such TI products as used in such applications. TI has not conducted any testing other than that specifically described in the published documentation for a particular TI Resource.

You are authorized to use, copy and modify any individual TI Resource only in connection with the development of applications that include the TI product(s) identified in such TI Resource. NO OTHER LICENSE, EXPRESS OR IMPLIED, BY ESTOPPEL OR OTHERWISE TO ANY OTHER TI INTELLECTUAL PROPERTY RIGHT, AND NO LICENSE TO ANY TECHNOLOGY OR INTELLECTUAL PROPERTY RIGHT OF TI OR ANY THIRD PARTY IS GRANTED HEREIN, including but not limited to any patent right, copyright, mask work right, or other intellectual property right relating to any combination, machine, or process in which TI products or services are used. Information regarding or referencing third-party products or services does not constitute a license to use such products or services, or a warranty or endorsement thereof. Use of TI Resources may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

TI RESOURCES ARE PROVIDED "AS IS" AND WITH ALL FAULTS. TI DISCLAIMS ALL OTHER WARRANTIES OR REPRESENTATIONS, EXPRESS OR IMPLIED, REGARDING TI RESOURCES OR USE THEREOF, INCLUDING BUT NOT LIMITED TO ACCURACY OR COMPLETENESS, TITLE, ANY EPIDEMIC FAILURE WARRANTY AND ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF ANY THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

TI SHALL NOT BE LIABLE FOR AND SHALL NOT DEFEND OR INDEMNIFY YOU AGAINST ANY CLAIM, INCLUDING BUT NOT LIMITED TO ANY INFRINGEMENT CLAIM THAT RELATES TO OR IS BASED ON ANY COMBINATION OF PRODUCTS EVEN IF DESCRIBED IN TI RESOURCES OR OTHERWISE. IN NO EVENT SHALL TI BE LIABLE FOR ANY ACTUAL, DIRECT, SPECIAL, COLLATERAL, INDIRECT, PUNITIVE, INCIDENTAL, CONSEQUENTIAL OR EXEMPLARY DAMAGES IN CONNECTION WITH OR ARISING OUT OF TI RESOURCES OR USE THEREOF, AND REGARDLESS OF WHETHER TI HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

You agree to fully indemnify TI and its representatives against any damages, costs, losses, and/or liabilities arising out of your non-compliance with the terms and provisions of this Notice.

This Notice applies to TI Resources. Additional terms apply to the use and purchase of certain types of materials, TI products and services. These include; without limitation, TI's standard terms for semiconductor products (<http://www.ti.com/sc/docs/stdterms.htm>), [evaluation modules](#), and [samples](http://www.ti.com/sc/docs/sampterm.htm) (<http://www.ti.com/sc/docs/sampterm.htm>).

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265
Copyright © 2017, Texas Instruments Incorporated