


# AM65x/DRA80xM Industrial Development Kit

Manufactured by Mistral Solutions Pvt. LTD. • [www.mistralsolutions.com](http://www.mistralsolutions.com)



Welcome to the AM65x/DRA80xM Industrial Development Kit (IDK) Quick Start Guide. This guide is designed to help you through the initial setup of the board. This IDK allows you to experience industrial applications which showcase the AM65x/DRA80xM Quad-Core Cortex®-A53, Dual-Core Cortex-R5F, gigabit PRU-ICSS (real-time industrial communications subsystem), and more. The IDK contains the following:

### Hardware

- AM6548/DRA804M Quad Core Cortex®-A53 function equivalent processor
- IDK Application card
- 2-lane PCIe SerDes card
- 4GB DDR4 with ECC
- On board 16 GB eMMC
- On board 512Mb OSPI Flash

### Printed Documents

- AM65x/DRA80xM IDK Quick Start Guide (this document)

### Miscellaneous

- 1 SD card
- 1 USB 2.0 cable
- 1 Ethernet cable

### Not included in box


The following hardware is not included in the box and must be procured separately:

1. Power supply. Use one of the following power supply options for powering up the IDK. Pick a power supply with all the applicable regional product regulatory/safety certification requirements such as UL, CSA, VDE, CCC, PSE, etc.

Connector	Specifications	Examples
Power DIN, 4 Pin	+24VDC, 5A Output (Max)	CUI Inc. SDI120-24-U-P51
Barrel Plug, 2.5mm I.D. x 5.5mm O.D. x 9.5mm	+24VDC, positive center, 2.71A Output (Max)	CUI Inc. SDI65-24-UD-P6

*The DIN connector power supply is recommended to provide enough power for applications that make use of the PCIe interface.*

2. 1280 x 800 LCD Display Accessory Kit. The LCD is optional and can be purchased separately using TI part number TMDSLCD1EVM.




## Default setup (TI-RTOS boot from SD card)


- 1** Optional: If you have purchased the LCD Accessory Kit, assemble the LCD onto the IDK following the instructions included with the LCD Accessory Kit.



- 2** Insert the SD card into the IDK. Alternatively, download and install the latest Processor SDK-RTOS from <http://www.ti.com/tool/processor-sdk-am65x>, create a bootable SD card and insert it into the IDK.



- 3** Connect a power supply (not included) to the DIN connector or power jack on the IDK and plug it in to an AC power source. Do not connect both, only one power supply must be connected.




- 4** Connect the supplied USB debug cable to the USB connector labeled “UART” on the board. Connect the other end to your PC. Then open a serial console on your PC such as Teraterm. Please note that you may need to download and install an FTDI driver from <http://www.ftdichip.com/FTDrivers.htm>.




**5** Optional: If you plan to use Code Composer Studio (CCS) IDE to control the IDK, you must use another USB cable connected to the USB connector labeled “XDS110\_USB” on the board. Refer to [http://software-dl.ti.com/processor-sdk-rtos/esd/docs/latest/rtos/How\\_to\\_Guides.html#host](http://software-dl.ti.com/processor-sdk-rtos/esd/docs/latest/rtos/How_to_Guides.html#host) for details about CCS setup.



**6** Turn on the IDK by sliding the toggle switch to the right. To turn off, slide the toggle switch the left.



**7** Note that this IDK comes with a coin battery holder. A coin battery is not necessary for normal operation of the IDK.



**Note:** This IDK is designed for optional use with a removable CR2032 UL recognized lithium battery (not supplied). Always use the CR2032VP Energizer 3V Lithium coin cell battery or similar CR2032 UL recognized battery with Nominal Voltage 3.0 Volts, Capacity 235mAh

TI Processor SDK software development guides are available at:  
Linux: [www.ti.com/processor\\_sdk\\_linux](http://www.ti.com/processor_sdk_linux)  
TI-RTOS: [www.ti.com/processor\\_sdk\\_rtos](http://www.ti.com/processor_sdk_rtos)  
Android: [www.ti.com/processor\\_sdk\\_android](http://www.ti.com/processor_sdk_android)

For more information on AM65x processors, including:

- User Guide
- Software
- How To
- Design Files

Please visit [www.ti.com/am65x](http://www.ti.com/am65x)

For support questions, please contact: [support@ti.com](mailto:support@ti.com) or [www.ti.com/e2e](http://www.ti.com/e2e)

**Important Notice:** The products and services of Texas Instruments Incorporated and its subsidiaries described herein are sold subject to TI's standard terms and conditions of sale. Customers are advised to obtain the most current and complete information about TI products and services before placing orders. TI assumes no liability for applications assistance, customer's applications or product designs, software performance, or infringement of patents. The publication of information regarding any other company's products or services does not constitute TI's approval, warranty or endorsement thereof.

Trademarks in this issue: The platform bar and Sitara are trademarks of Texas Instruments. All other trademarks are the property of their respective owners.

## IMPORTANT NOTICE AND DISCLAIMER

TI PROVIDES TECHNICAL AND RELIABILITY DATA (INCLUDING DATASHEETS), DESIGN RESOURCES (INCLUDING REFERENCE DESIGNS), APPLICATION OR OTHER DESIGN ADVICE, WEB TOOLS, SAFETY INFORMATION, AND OTHER RESOURCES "AS IS" AND WITH ALL FAULTS, AND DISCLAIMS ALL WARRANTIES, EXPRESS AND IMPLIED, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

These resources are intended for skilled developers designing with TI products. You are solely responsible for (1) selecting the appropriate TI products for your application, (2) designing, validating and testing your application, and (3) ensuring your application meets applicable standards, and any other safety, security, or other requirements. These resources are subject to change without notice. TI grants you permission to use these resources only for development of an application that uses the TI products described in the resource. Other reproduction and display of these resources is prohibited. No license is granted to any other TI intellectual property right or to any third party intellectual property right. TI disclaims responsibility for, and you will fully indemnify TI and its representatives against, any claims, damages, costs, losses, and liabilities arising out of your use of these resources.

TI's products are provided subject to TI's Terms of Sale ([www.ti.com/legal/termsofsale.html](http://www.ti.com/legal/termsofsale.html)) or other applicable terms available either on [ti.com](http://ti.com) or provided in conjunction with such TI products. TI's provision of these resources does not expand or otherwise alter TI's applicable warranties or warranty disclaimers for TI products.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265  
Copyright © 2019, Texas Instruments Incorporated