

DRV8711 Decay Mode Setting Optimization

Wilson Zuo, Axel Gao

ABSTRACT

This document is provided as a guide to the decay parameters adjustment for the DRV8711 at highdegree micro stepping to achieve the best sinusoidal current. It analyzes 6 typical abnormal winding current waveforms of stepper and offers a respectively simple method to fix the problem by modifying only 1 parameter. All the analysis and experiments are tested with the DRV8711 EVM. But the conclusions are valid to the other stepper driver. Almost all the abnormal winding current waveforms are seen as the combination of the 6 typical abnormal waveforms and the solution could be also the combination of the introduced methods.

Contonto

	Contents	
1	Introduction	2
2	Current Distortion Pattern 1	3
	2.1 Adjustment Method 1	3
	2.2 Adjustment Method 2	4
3	Current Distortion Pattern 2	5
	3.1 Adjustment Method 1	5
	3.2 Adjustment Method 2	6
4	Current Distortion Pattern 3	7
	4.1 Adjustment Method 1	7
	4.2 Adjustment Method 2	8
5	Current Distortion Pattern 4	9
	5.1 Adjustment Method 1	9
	5.2 Adjustment Method 2	10
6	Current Distortion Pattern 5	11
	6.1 Adjustment Method	11
7	Current Distortion Pattern 6	12
	7.1 Adjustment Method	13
8	Summary	13

Figures

Figure 1.	Ideal Winding Current Waveform of 1/256 Micro Stepping	2
Figure 2.	Current Distortion Pattern 1	
Figure 3.	Current Distortion Pattern 2	5
Figure 4.	Current Distortion Pattern 3	7
Figure 5.	Current Distortion Pattern 4	9
Figure 6.	Current Distortion Pattern 5	11
Figure 7.	Current Distortion Pattern 6	12



1 Introduction

High resolution micro stepping is widely used in security cameras, CNC systems, stage lighting, and other applications requiring smooth movement. The DRV8711, which is a stepper motor controller with an integrated indexer, achieves step modes from full step to 1/256-step and is adequate to these high resolution applications. Figure 1 illustrates to 1/256-step, the ideal waveform of winding current is sinusoidal.



Figure 1. Ideal Winding Current Waveform of 1/256 Micro Stepping

The ideal sinusoidal winding current could match the magnetic natural characteristic of a stepper and assure the stepper to have a smooth and uniform movement in high degree micro-stepping. However, due to the different electrical parameters and different motors, there are always some difficulties in realizing a perfect sinusoidal wave. The current profile is actually the result of the detailed decay settings. Since the <u>DRV8711</u> gives the most flexibility of decay mode configuration including slow, fast, mixed, slow+mixed, slow+auto mixed, and auto mixed 6 modes and related detail tunings, we chose the <u>DRV8711 EVM</u> to demonstrate the adjustment methods.

This application note analyzes the decay adjustment methods to fix the typical abnormal waveforms of winding current. All the following adjustments attempt to just change one parameter at a time, such as off-time, blanking time, decay time, and decay mode, in order to give the clear trend of each parameter's change. In real applications, there could be a combination of parameters tunings to get the most optimized result with the least side effects.

Motor	Phase Resistance	Phase Inductance	Description
Motor 1	0.8 Ohm	3.5 mH @ 1 kHz	Normal inductive
Motor 2	1.1 Ohm	7 mH @ 1 kHz	Large inductive

The following experiments are all completed in a laboratory environment with 2 different motors, respectively, as listed in the following table:







Test conditions: DRV8711EVM, VM = 24 V, I_{torque} = 2.5 A, Micro-step = 1/256, Motor 1.





Figure 1 shows the winding current stays at a higher level than the ideal waveform during the current increasing stage. This distortion is mainly caused by the current decay rate being too slow and usually happens to a stepper with low phase resistance and inductance.

2. How does the adjustment work?

Fix this problem by replacing slow decay with mixed decay during the current increasing stage because mixed decay has a faster decay rate than slow decay.

2.2 Adjustment Method 2



1. Root cause analysis:

The same as Section 2.1

2. How does the adjustment work?

To make the winding current decay more, we could also prolong the off-time . Therefore, PWM off-time increases from 9 $\,\mu s$ to 32 $\,\mu s$, which has an effective influence on the current waveform.





Figure 3. Current Distortion Pattern 2

Test conditions: DRV8711EVM, VM = 24 V, I_{torque} = 2.5 A, Micro-step = 1/256, Motor 2.





As shown in Figure 2, the winding current is overcharged at the end of the current level-up stage. This is mainly due to the long blanking time and the slow decay rate.

2. How does the adjustment work?

To fix this problem, reduce the charged current by cutting down the blanking time. There is an effective influence on the current waveform, as shown in the chart above.

3.2 Adjustment Method 2



The same as for section 2.1.

2. How does the adjustment work?

The other method is increasing off-time to reduce more current during the current decay stage. The previous chart shows the effect of increasing off-time from 18 μ s to 26 μ s.







Test conditions: DRV8711EVM, VM = 24 V, I_{torque} = 2.5 A, Micro-step = 1/256. Motor 1.





As shown in Figure 3, the winding current is overcharged at the end of the current level-down stage, especially around the 0 point. This is mainly due to the long blanking time resulting in too much charged current above the command level.

2. How does the adjustment work?

To avoid charging too much current, cut down the blanking time. The chart above shows the effect of reducing blanking time from 2.6 μ s to 1.5 μ s.

4.2 Adjustment Method 2



1. Root cause analysis:

The same as section 3.1.

2. How does the adjustment work?

The other method is to increase the decay time, because the more fast decay, the more current is eliminated. The chart above shows the effect.







Test conditions: DRV8711EVM, VM = 24 V, I_{torque} = 2.5 A, Micro-step = 1/256. Motor 1.





This abnormal waveform is an extreme situation of distortion pattern 1 and pattern 2. It is extremely overcharged due to the slow rate of slow decay in current level-up stage.

2. How does the adjustment work?

To avoid charging too much current, replacing slow decay with mixed decay is effective. The chart above shows the effect of modifying the decay mode to all mixed decay.

5.2 Adjustment Method 2



1. Root cause analysis:

The same as for section 4.1.

2. How does the adjustment work?

To deal with this extreme overcharge situation, not only blanking time needs reduction but also increasing off-time. From the chart above, the effect of reducing blanking time from 3 μ s to 0.5 μ s and increasing off-time from 6 μ s to 20 μ s is illustrated.







Test conditions: DRV8711EVM, VM = 24 V, I_{torque} = 2.5 A, Micro-step = 1/256. Motor 1.





This abnormal waveform has a large ripple and an obvious plateau around zero current point. It's mainly due to too much current eliminated by fast decay in the off time and the lowered average current causing a flat zero distortion.

2. How does the adjustment work?

To avoid consuming too much current and keep fast decay, reduce off-time. From the chart above, the plateau around the 0 point disappears and the current ripple gets smaller by decreasing off-time from 30 μ s to 4 μ s.

Also, the current ripple is cured by lowering the off time which increases the total PWM frequency.



7 Current Distortion Pattern 6

Figure 7. Current Distortion Pattern 6

Test conditions: DRV8711EVM, VM = 24 V, I_{torque} = 2.5 A, Micro-step = 1/256. Motor 1.



7.1 Adjustment Method

Before Adjustment	After Adjustment	
100 A 20.0ms 20.0ms 20.0ms 3M points 20.0mA 25.0MS/s 20.0mA 26 Bec 2013 14:00: 51	18kSthur 193/3 19 /3	
DECMOD (decay mode): 101 All AutoMixed	DECMOD (decay mode): 101 All AutoMixed	
TBLANK (blanking time): 0.5 μs	TBLANK (blanking time): 2.5 µs	
ABT(adaptive blanking time): 0	ABT(adaptive blanking time): 0	
TDECAY (decay time): 3 µs	TDECAY (decay time): 3 µs	
TOFF(PWM off time): 7.5 μs	TOFF(PWM off time): 7.5 μs	

1. Root cause analysis:

Auto-mixed decay is a peculiar decay mode of the DRV8711, refer to the datasheet (<u>SLVSC40</u>) for the detailed function. For this motor, here the distortion is because of too small a blanking time which causes the total decay effect in auto mixed decay to be too low for the current command level change.

2. How does the adjustment work?

By increasing the blanking time, the auto mixed decay is able to decay the current to the index command level.

8 Summary

In real practice, the combination of adjustment methods shown in this application report efficiently leads to the best sinusoidal current waveform of different applications. The adjustment trends are also valid to other micro stepping levels, current level settings, motor types, and other DRV8x stepper drivers with related adjustable parameters. The adjustment practice should be done at low speed in which the back electromotive force (BEMF) effect could be ignored. When motor speed increases, meaning the current index commands change faster, and including the BEMF effect, there is a speed point that the the sinusoidal current waveform can no longer maintain. Proper decay parameters increase the speed threshold of maintaining the sinusoidal current waveform.

IMPORTANT NOTICE

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, enhancements, improvements and other changes to its semiconductor products and services per JESD46, latest issue, and to discontinue any product or service per JESD48, latest issue. Buyers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All semiconductor products (also referred to herein as "components") are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its components to the specifications applicable at the time of sale, in accordance with the warranty in TI's terms and conditions of sale of semiconductor products. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by applicable law, testing of all parameters of each component is not necessarily performed.

TI assumes no liability for applications assistance or the design of Buyers' products. Buyers are responsible for their products and applications using TI components. To minimize the risks associated with Buyers' products and applications, Buyers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any patent right, copyright, mask work right, or other intellectual property right relating to any combination, machine, or process in which TI components or services are used. Information published by TI regarding third-party products or services does not constitute a license to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of significant portions of TI information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. TI is not responsible or liable for such altered documentation. Information of third parties may be subject to additional restrictions.

Resale of TI components or services with statements different from or beyond the parameters stated by TI for that component or service voids all express and any implied warranties for the associated TI component or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

Buyer acknowledges and agrees that it is solely responsible for compliance with all legal, regulatory and safety-related requirements concerning its products, and any use of TI components in its applications, notwithstanding any applications-related information or support that may be provided by TI. Buyer represents and agrees that it has all the necessary expertise to create and implement safeguards which anticipate dangerous consequences of failures, monitor failures and their consequences, lessen the likelihood of failures that might cause harm and take appropriate remedial actions. Buyer will fully indemnify TI and its representatives against any damages arising out of the use of any TI components in safety-critical applications.

In some cases, TI components may be promoted specifically to facilitate safety-related applications. With such components, TI's goal is to help enable customers to design and create their own end-product solutions that meet applicable functional safety standards and requirements. Nonetheless, such components are subject to these terms.

No TI components are authorized for use in FDA Class III (or similar life-critical medical equipment) unless authorized officers of the parties have executed a special agreement specifically governing such use.

Only those TI components which TI has specifically designated as military grade or "enhanced plastic" are designed and intended for use in military/aerospace applications or environments. Buyer acknowledges and agrees that any military or aerospace use of TI components which have *not* been so designated is solely at the Buyer's risk, and that Buyer is solely responsible for compliance with all legal and regulatory requirements in connection with such use.

TI has specifically designated certain components as meeting ISO/TS16949 requirements, mainly for automotive use. In any case of use of non-designated products, TI will not be responsible for any failure to meet ISO/TS16949.

Products		Applications		
Audio	www.ti.com/audio	Automotive and Transportation	www.ti.com/automotive	
Amplifiers	amplifier.ti.com	Communications and Telecom	www.ti.com/communications	
Data Converters	dataconverter.ti.com	Computers and Peripherals	www.ti.com/computers	
DLP® Products	www.dlp.com	Consumer Electronics	www.ti.com/consumer-apps	
DSP	dsp.ti.com	Energy and Lighting	www.ti.com/energy	
Clocks and Timers	www.ti.com/clocks	Industrial	www.ti.com/industrial	
Interface	interface.ti.com	Medical	www.ti.com/medical	
Logic	logic.ti.com	Security	www.ti.com/security	
Power Mgmt	power.ti.com	Space, Avionics and Defense	www.ti.com/space-avionics-defense	
Microcontrollers	microcontroller.ti.com	Video and Imaging	www.ti.com/video	
RFID	www.ti-rfid.com			
OMAP Applications Processors	www.ti.com/omap	TI E2E Community	e2e.ti.com	
Wireless Connectivity	www.ti.com/wirelessconnectivity			

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265 Copyright © 2014, Texas Instruments Incorporated