



Brushless DC Motor with Speed Control, TI Design


This design has a simple power connector that accepts 24V to 32V, and the motor spins at 2054 RPM. If a lower RPM is set (with resistor R13), a lower voltage down to 8.5V can also be used. Data in this report was taken using 24V. Motor current is limited to 5.2A using the DRV8308 V_{LIMITER} feature.



Test Setup




RPM and Supply Current vs Torque




Most BLDC motors do not have closed-loop speed control, so RPM will decrease unpredictably as torque increases. But the DRV8308 maintains a precise RPM. The operating torque range of this design is 0 to 118 mNm (16.7 oz-in), and maximum motor power is 25W.

Power Efficiency vs Torque




Power Efficiency = Motor Power / Supply Power = (Torque * Speed) / (Voltage * Current).

Spin-up Profile with No Load




Motor speed was measured from the frequency of one Hall signal, and converted to this an analog waveform. Spin-up time was 60ms. The steady-state value represents 2054 RPM.

Spin-up Profile with 100 mNm Load




Again, motor speed was measured from the frequency of one Hall signal, and converted to this an analog waveform. Spin-up time was 680ms. The steady-state value represents 2054 RPM.

Transient Response of Speed, Going from 22.8 mNm to 90 mNm





The waveform amplitude represents 2054 RPM. During the first 750ms, a 22.8 mNm load was driven, and then there was a step-change in load to 90 mNm. The DRV8308 closed-loop control compensated very effectively.

Transient Response of Speed, Going from 90 mNm to 22.8 mNm



Again, the waveform amplitude represents 2054 RPM. During the first 500ms, a 90 mNm load was driven, and then there was a step-change in load to 22.8 mNm. The speed overshoot was about 1.5%.

Thermal Images with 1.6A, 106 mNm Load, and 2054 RPM




Flutter with No Load (measured from a Hall signal)

0.30%


Flutter is a measure of rotational speed jitter, and it measures the edge variation of a periodic signal generated by the motor. It is most accurately measured from a serpentine board trace that senses magnetic reluctance, but in this case a Hall signal was used. The DRV8308 commutates based on 1 Hall sensor, and that improves flutter.

Input clock to the DRV8308



This clock is applied to DRV8308 pin “CLKIN”. The device matches the frequency of Hall U with the frequency of this reference clock.

Hall-effect sensor signal



The motor has 10 permanent magnet poles, so there are 5 Hall cycles per revolution. $171\text{Hz} / 5 * 60 = 2054\text{ RPM}$.

IMPORTANT NOTICE AND DISCLAIMER

TI PROVIDES TECHNICAL AND RELIABILITY DATA (INCLUDING DATA SHEETS), DESIGN RESOURCES (INCLUDING REFERENCE DESIGNS), APPLICATION OR OTHER DESIGN ADVICE, WEB TOOLS, SAFETY INFORMATION, AND OTHER RESOURCES "AS IS" AND WITH ALL FAULTS, AND DISCLAIMS ALL WARRANTIES, EXPRESS AND IMPLIED, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

These resources are intended for skilled developers designing with TI products. You are solely responsible for (1) selecting the appropriate TI products for your application, (2) designing, validating and testing your application, and (3) ensuring your application meets applicable standards, and any other safety, security, regulatory or other requirements.

These resources are subject to change without notice. TI grants you permission to use these resources only for development of an application that uses the TI products described in the resource. Other reproduction and display of these resources is prohibited. No license is granted to any other TI intellectual property right or to any third party intellectual property right. TI disclaims responsibility for, and you will fully indemnify TI and its representatives against, any claims, damages, costs, losses, and liabilities arising out of your use of these resources.

TI's products are provided subject to [TI's Terms of Sale](#) or other applicable terms available either on [ti.com](#) or provided in conjunction with such TI products. TI's provision of these resources does not expand or otherwise alter TI's applicable warranties or warranty disclaimers for TI products.

TI objects to and rejects any additional or different terms you may have proposed.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265
Copyright © 2021, Texas Instruments Incorporated